

# CORROFLON

**Convoluted PTFE Lined Hose** 



CHEMICAL RESISTANT KINK RESISTANT SELF CLEANING FLEXIBLE


HYGIENIC


#### INTRODUCTION TO CORROFLON

CONDITIONS OF SALE	Pages 38 & 39
CONDITIONS OF SALE	
Length Calculation	Page 30 Page 37
Abrasion & Torque	Page 35 Page 36
CORRECT HOSE CONFIGURATION & LENGTH CALCULATIONS  • Bend Radius	Dade 35
	r age JT
CORROFLON STANDARD LABELLING, STREAMLINE TAGGING & COLOUR CODING	Page 34
Electrically Trace Heated Hose Assemblies (ETH Grade)	Page 32 Page 33
<ul> <li>Insulated Hose Assemblies</li> <li>Steam Heated Hose Assemblies (CH Grade)</li> </ul>	Page 31 Page 32
HEAT JACKETED HOSE ASSEMBLIES	Dago 21
	raye su
90°ELBOW FITTINGS • 90° Elbow Fittings, PTFE Lined and Non-Lined	Page 30
	raye 29
• PTFE Dip Pipes, Straight or 90° Elbow	Page 29
• 37° JIC Female Fittings & NPT Male or Female Unions	Page 28
• BSP 60° Cone Seat Female Fittings and Lug-Type Female Fittings	Page 20 Page 27
• NPT & BSPT Fixed Male and NPT Fixed Female Fittings	Page 26
BSP, NPT & JIC THREADED FITTINGS (Not Lined)	
<ul> <li>DIN11851 Male &amp; Female Fittings, PTFE Lined and DIN11851 Female Fittings, Non-Lined</li> <li>SMS and RJT Female Fittings, PTFE Lined</li> </ul>	Page 24 Page 25
HYGIENIC FITTINGS (EUROPEAN)     IDIN11851 Male & Female Eittings, PTEE Lined and DIN11851 Female Eittings, Non-Lined	Page 24
	1 uge 20
• 90° Elbow Sanitary Triclover Fittings, Not Lined	Page 22 Page 23
Mini Sanitary & Sanitary Triclover Fittings, PTFE Lined     Mini Sanitary & Sanitary Triclover Fittings, Not Lined	Page 21 Page 22
SANITARY (TRICLOVER) FITTINGS <ul> <li>Mini Sanitary &amp; Sanitary Triclover Fittings, PTFE Lined</li> </ul>	Page 21
	. uge 20
<ul> <li>Perhate Carrie Carrier &amp; Groove Fittings, PTFE Lined and Not Lined</li> <li>Male Carrier &amp; Groove Fittings, PTFE Lined and Not Lined and Carrier Male-to-Flange Adaptors, PTFE Lined</li> </ul>	Page 19 Page 20
CAM AND GROOVE FITTINGS (CAMLOCKS)  • Female Cam & Groove Fittings, PTFE Lined and Not Lined	Page 19
Flange Fittings, PTFE Lined	Page 18
Flange Fittings, Non-Lined	Page 17
FLANGE FITTINGS	-
Corroflon External Protection Systems	Page 16
Corroflon Rubber Covers	Page 15
Corroflon Hose Braids (and Electrical Continuity)	Page 14
Corroflon Hose Liners	Page 13
HOSE	
Corroflon Part Number System	Page 12
Corroflon EN 16643 Hose Assembly Electrical Property Grades	Page 11
How to Order Corroflon	Page 10
Quality Assurance Certification & Approvals and Hose Testing	Page 9
<ul> <li>Corroflon Sizes, Grades, Pressure Ratings and Weights</li> <li>Corroflon Special Usage Conditions</li> </ul>	Page 7 Page 8
Corroflon Sizes, Grades, Bend Radius and Dimensions     Corroflon Sizes, Grades, Pressure Patings and Weights	Page 6 Page 7
Corroflon Temperatures, Pressures & Flow Rates     Corroflon Sizes, Grades, Bend Padius and Dimensions	Page 5 Page 6
Corroflon Hose Description	Page 4
PTFE - The Optimum Choice For Hose Linings	Page 3
Contents	Page 2
INTRODUCTION TO CORROFLON	

## **PTFE - THE OPTIMUM CHOICE FOR HOSE LININGS**

Section from a PTFE Molecule, 16 Angstrom Units long





PTFE, or Polytetrafluoroethylene, comprises of long-chain molecules of carbon atoms, each linked to two fluorine atoms.

The fluorine atoms provide a helical spiral which surrounds the carbon chain and protects it.

It is this structure which creates the unique properties for which PTFE is well-known.

#### Excellent Chemical Resistance

PTFE is renowned as the most chemically resistant material known. Only a very few, very unusual substances and conditions can affect it, like Fluorine gas at high temperature and pressure and liquid, boiling sodium metal.

PTFE lined hoses can therefore be used for a wider variety of chemicals than any other hose type, making it the ideal choice for very corrosive chemical applications and multiproduct applications.

#### Non-Stick Surface

The use of PTFE as a surface for cookware products has demonstrated to the world how easily cleanable PTFE surfaces are.

This means that PTFE lined hoses can be purged 100% clean more quickly, easily and reliably than any other type of hose.

#### Excellent Temperature Range

The cookware application also demonstrates another of PTFE's many attributes - temperature resistance. PTFE itself can be used as a hose liner at temperatures from  $-150^{\circ}$ C up to  $+260^{\circ}$ C, dependent upon the hose design and the application conditions.

This is the widest temperature range of any rubber or plastic hose lining material.

#### Hose Design

The only issue with PTFE as a hose lining material is the best way it can be integrated in to the hose design. This is where Aflex Hose have a proven record of success over the last 40 years.

#### **CORROFLON HOSE DESCRIPTION**

Secondly, Corroflon is the only PTFE lined convoluted hose on the

market to be fully kink and vacuum resistant at high pressures and

temperatures. This is because Corroflon's design incorporates a thick section external helical reinforcement wire which gives the

radial support necessary to ensure maximum strength, whilst maintaining optimum flexibility and cleanability. The helix wire is

welded directly to the end fittings at each end, ensuring security

And thirdly, Aflex is the only PTFE hose manufacturer to guarantee

a minimum PTFE liner thickness of 1.5mm for hose sizes 1" and

above, which ensures sufficient strength to prevent the tube from being internally pressurised from a sine wave shape into an

extended square wave shape, which would lead to porosity, and

eventually premature failure of the tube. This thick wall liner also minimises permeation, and is extended through the end fittings to

give an uninterrupted clean flow of fluid through the fitting.


of attachment and electrical continuity.


Aflex Hose pioneered the concept of PTFE lined flexible hose for the transfer of process fluids more than 40 years ago.

Corroflon convoluted bore and Bioflex Ultra, Corroline+ and Pharmaline smoothbore hose, all manufactured and supplied by Aflex, are used by major Chemical, Pharmaceutical and Food companies worldwide.


Over the years, hundreds of thousands of custom-built hoses have been designed and built to cope with the most difficult of operating conditions, and we have continuously developed and expanded our product range to meet increasingly stringent customer demands.

#### **CORROFLON GP, SS HOSE & PTFE LINED FLANGE FITTING**





#### **CORROFLON GP PTFE HOSE**



## **CORROFLON SPECIFICATIONS TEMPERATURES, PRESSURES & FLOW RATES**

#### Maximum Working Pressure (MWP) Variation with Temperature:

Hose with SS Braid as per Graph.

Hose with PB Braid, pressure as listed (Page 7) from -22°F to +176°F and 50% less from 176°F to 212°F.

Hose with RC and SI grades as per Graph, BUT only within the temperature range for the particular grade of rubber cover, as given below.

Maximum Operating Temperatures (Internal Fluid Only) for different hose grades:

SS PΒ SS.RC & SS SS. SI KYB

-100°F through +500°F -22°F through +212°F -40°F through +302°F -100°F through +435°F -40°F through +248°F

(Subtract 36°F from the above maximum temperature limits if the temperature is external to the hose).

#### Temperature vs Vacuum

All sizes of Corroflon GP,SS and AS, SS are usable at vacuum to -0.9bar up to 302°F up to 2". Above this, the vacuum resistance should be reduced 1% for every 1.8 degreeS above 302°F.

Other grades the same, BUT ONLY within the temperature limits for the particular hose grade.

#### Flow Rates

- For maximum flow rates, it is better to use the smooth bore Bioflex hose if possible, because the convoluted bore of Corroflon creates turbulent flow, which reduces flow rates.

#### **Corroflon Hose - Flow Rate Calculation**

If it is required to determine the flow rate of a particular hose assembly, or if it is required to determine the pressure required to generate a certain flow rate, then this can sometimes be approximately calculated by the Corroflon supplier.

It should be noted that calculations can only be made for fluids with a viscosity equal to water, and for hose assemblies with PTFE lined end fittings (no bore restrictions at the ends of the hose).

The following information should be given to the supplier:

To calculate the Flow Rate in Cubic Metres per Hour:


- Pressure in psi at the Entry into the Hose Assembly
- Pressure in psi at the Exit from the Hose Assembly
- The hose configuration (roughly straight, or 33% Bends, or 66% Bends, or 100% Tightly Coiled)

OR To Calculate the Pressure Drop in bars over the length of the Hose Assembly:

- Required Flow Rate in Cubic Metres per Hour
- The hose configuration (roughly straight, or 33% Bends. or 66% Bends, or 100% Tightly Coiled)

#### Whistling

A 'whistling' noise may be created by turbulent flow when steam or other gasses are passed through a Corroflon hose at high flow rates. In such applications, Bioflex hose represents an alternative option which eliminates this problem.



(Subtracted to calculate Pressure Drop over the Hose Length)

## CORROFLON SIZES, GRADES, BEND RADIUS AND DIMENSIONS

## CORROFLON SIZES, GRADES, PRESSURE RATINGS & WEIGHTS

	ninal Hose ore Size		Inside Iutions	Corroflon Grade (Braid & Cover)		ner Tube ickness		f Tube, r Rubber	Mini Bend F		Conti	kimum nuous Length
in	mm	in	mm		in	mm	in	mm	in	mm	Ft	Mtrs
1/2	15	0.440	11.2	TO SS PB SS, RC RC, SI KYB	0.05	1.4	0.63 0.70 0.80 0.90 0.90 0.76	16.1 17.8 20.4 22.8 22.8 19.3	1 <sup>1</sup> / <sub>2</sub> 1 <sup>1</sup> / <sub>2</sub> 1 <sup>1</sup> / <sub>2</sub> 2 <sup>1</sup> / <sub>4</sub> 2 <sup>1</sup> / <sub>4</sub> 1 <sup>1</sup> / <sub>2</sub>	38 38 38 57 57 38	100 100 100 100 100 100	30 30 30 30 30 30 30
3/4	20	0.620	15.7	TO SS PB SS, RC RC, SI KYB	0.05	1.4	0.85 0.91 1.02 1.11 1.11 0.97	21.5 23.2 25.8 28.2 28.2 24.7	2 2 3 3 2	51 51 56 76 51	100 100 100 100 100 100	30 30 30 30 30 30 30
1	25	0.847	21.5	TO SS PB SS, RC RC, SI KYB	0.06	1.5	1.08 1.14 1.25 1.34 1.34 1.20	27.4 29.1 31.7 34.1 34.1 30.6	2 <sup>3</sup> /4 2 <sup>3</sup> /4 2 <sup>3</sup> /4 4 <sup>1</sup> /4 4 <sup>1</sup> /4 2 <sup>3</sup> /4	70 70 70 105 105 70	100 100 100 100 100 100	30 30 30 30 30 30 30
1 <sup>1</sup> /4	32	1.080	27.5	TO SS PB SS, RC RC, SI KYB	0.06	1.5	1.45 1.53 1.72 1.72 1.72 1.57	36.8 38.8 43.6 43.8 43.8 40.0	3 <sup>1</sup> /4 3 <sup>1</sup> /4 3 <sup>1</sup> /4 4 <sup>3</sup> /4 3 <sup>1</sup> /4	82 82 123 123 82	100 100 100 100 100 100	30 30 30 30 30 30 30
11/2	40	1.250	32.0	TO SS PB SS, RC RC, SI KYB	0.06	1.5	1.65 1.74 1.92 1.93 1.93 1.78	42.0 44.1 48.8 49.1 49.1 45.2	4 4 6 6 4	100 100 100 150 150 100	100 100 100 100 100 100	30 30 30 30 30 30 30
2	50	1.690	43.0	TO SS PB SS, RC RC, SI KYB	0.07	1.8	2.11 2.19 2.37 2.38 2.38 2.23	53.5 55.6 60.3 60.6 60.6 56.7	5 <sup>1</sup> /2 5 <sup>1</sup> /2 5 <sup>1</sup> /2 8 <sup>1</sup> /4 8 <sup>1</sup> /4 5 <sup>1</sup> /2	140 140 140 210 210 140	100 100 100 100 100 100	30 30 30 30 30 30 30
21/2	65	2.120	54.0	TO SS PB SS, RC RC, SI KYB	0.07	1.8	2.75 2.83 3.01 3.03 3.03 2.87	69.8 71.9 76.6 76.9 76.9 73.0	7 7 7 10 <sup>1</sup> /2 10 <sup>1</sup> /2 7	178 178 178 267 267 178	65 65 65 65 65 65	20 20 20 20 20 20 20
3	80	2.500	64.0	TO SS PB SS, RC RC, SI KYB	0.07	1.8	3.27 3.37 3.53 3.57 3.57 3.39	83.0 85.7 89.8 90.7 90.7 86.2	9 9 13 <sup>1</sup> /2 13 <sup>1</sup> /2 9	230 230 230 345 345 230	65 65 65 65 65 65	20 20 20 20 20 20 20
4	100	3.860	98.0	TO SS PB SS, RC RC, SI KYB	0.10	2.5	4.17 4.28 4.44 4.48 4.48	106.0 108.7 112.8 113.7 113.7	113/4 113/4 113/4 173/4 173/4	300 300 300 450 450	32 32 32 32 32 32	10 10 10 10 10
б * Longer	150 lengths may be a	5.250 available to spe	130.0 cial order	TO SS PB SS, RC RC, SI KYB	0.12	3.0	5.75 5.87 - 6.06 6.06	146.0 149.0 - 154.0 154.0	23 <sup>3</sup> /4 23 <sup>3</sup> /4 35 <sup>1</sup> /2 35 <sup>1</sup> /2	600 600 - 900 900 -	13 13 - 13 13 -	4 4 4 4 -

	al Hose Size		Inside Iutions	Corroflon Grade (Braid & Cover)	Maximun Pressure		Burst P	ressure	Weigl Unit L	
in	mm	in	mm		Bar	psi	Bar	psi	Kg/Mtr	Lb/ft
1/2	15	0.440	11.2	TO SS PB SS, RC RC, SI KYB	6 41 31 41 41 15	87 595 450 595 595 215	24 450 150 450 450 61.5	350 6525 2175 6525 6525 890	0.21 0.33 0.26 0.49 0.49 0.23	0.14 0.22 0.17 0.33 0.33 0.15
3/4	20	0.620	15.7	TO SS PB SS, RC RC, SI KYB	5 35 26 35 35 13	70 505 375 505 505 190	20 240 105 240 240 52.5	290 3480 1520 3480 3480 760	0.29 0.45 0.36 0.56 0.56 0.31	0.19 0.30 0.24 0.38 0.38 0.21
1	25	0.847	21.5	TO SS PB SS, RC RC, SI KYB	4.5 31 23 31 31 11	65 450 334 450 450 160	18 200 93 200 200 46.5	260 2900 1350 2900 2900 675	0.45 0.70 0.56 0.98 0.98 0.49	0.30 0.47 0.38 0.66 0.66 0.33
11/4	32	1.080	27.5	TO SS PB SS, RC RC, SI KYB	4 27 20 27 27 10	58 390 290 390 390 145	16 180 81 180 180 40.5	230 2610 1175 2610 2610 585	0.53 0.82 0.66 1.12 1.12 0.57	0.36 0.55 0.44 0.75 0.75 0.38
11/2	40	1.250	32.0	TO SS PB SS, RC RC, SI KYB	3.5 23 17 23 23 9	50 335 245 335 335 130	14 120 69 120 120 34.5	205 1740 1000 1740 1740 500	0.97 1.50 1.20 1.90 1.90 1.05	0.65 1.01 0.80 1.27 1.27 0.70
2	50	1.690	43.0	TO SS PB SS, RC RC, SI KYB	3 20 15 20 20 8	44 290 215 290 290 115	12 100 60 100 100 30	175 1450 870 1450 1450 435	1.36 2.10 1.68 2.72 2.72 1.47	0.91 1.41 1.13 1.82 1.82 0.99
21/2	65	2.120	54.0	TO SS PB SS, RC RC, SI KYB	2.5 16 12 16 16 6	36 230 175 230 230 87	10 70 48 70 70 24	145 1015 695 1015 1015 350	1.68 2.58 2.06 3.10 3.10 1.81	1.13 1.73 1.38 2.08 2.08 1.21
3	80	2.500	64.0	TO SS PB SS, RC RC, SI KYB	2 14 10 14 14 5	29 205 145 205 205 73	8 60 42 60 60 21	115 870 610 870 870 305	2.14 3.29 2.63 3.95 3.95 2.30	1.43 2.20 1.76 2.65 2.65 1.54
4	100	3.860	98.0	TO SS PB SS, RC RC, SI KYB	1.5 10 8 10 10 -	22 145 115 145 145 -	6 40 30 40 40	87 580 435 580 580	3.18 5.05 3.98 6.12 6.14 -	2.13 3.38 2.67 4.10 4.11
6	150	5.250	130.0	TO SS PB SS, RC RC, SI KYB	0.75 5 - 5 5 -	11 73 - 73 73 -	3 20 - 20 20 -	44 290 - 290 290 -	6.50 10.00 12.00 12.00	4.36 6.70 - 8.04 8.04 -

#### Cleaning & Sterilising Systems - CIP, SIP and Autoclave

CIP & SIP - PTFE liner tubes are chemically resistant to all CIP, SIP and Autoclave conditions. The primary consideration is whether the cleaning and purging cycle is likely to develop an electrostatic charge on the internal surface of the liner, in which case AS (Anti-Static) grade hose is required.

AS grade hose and Electrostatic charge generating systems are fully described in the hose liner section.

CIP systems using high electrical resistivity solvents like Toluene will require AS grade hose.

Another electrostatic generation problem arises when wet steam is used, or when the cleaning fluids or WFI are purged out of the line using nitrogen, compressed air or another gas, because droplets of liquid or water in the gas then generate a multi-phase condition until they are cleared out, which will generate a static charge, and so will require AS grade hose.

In static generating applications where AS grade hose is not acceptable due to the black PTFE liner, alternative solutions are available - please consult Aflex Hose for advice.

Autoclave - Autoclave sterilisation does not normally involve any high flow rates through the hose bore, so static generation is not a problem. Aflex hose grades GP and AS, with SS or HB braids are fully resistant to all autoclave conditions throughout the service life of the hose.

The rubber covered grades EPDM, (RC) and Silicone Rubber (RC, SI) are able to withstand at least 100 x 30 minute autoclave cycles at relatively high autoclave temperatures (121°C, 250°F or 135°C, 275°F). Consult Aflex Hose for more specific information.

#### PTFE Hose-Use with Alkali Metals, Halogens and Halogen containing Chemicals

PTFE hose liners react chemically with Fluorine, Chlorine Trifluoride and molten Alkali Metals.

When PTFE lined hose is used to carry Chlorine or Bromine, either as gasses or fluids, they will diffuse into and through the PTFE liner wall thickness. Trace quantities will then combine with atmospheric moisture to corrode any braid/rubber outer coverings.

Heavily halogenated chemicals, like Hydrogen Fluoride, Hydrogen Chloride, Phosgene (Carbonyl Chloride) Carbon Tetrachloride and other organic chemicals with a high halogen content can also be absorbed and transmitted through the PTFE liner tube.

#### Other "Penetrating" Fluids and Gases

Sulphur Trioxide, Methyl Methacrylate, Caprolactam and Glacial Acetic Acid are some other chemicals which can be absorbed and transmitted through the PTFE liner tube wall.

Generally, however, as a hydrophobic (non-wetting) material, PTFE is very resistant to the absorption of chemicals. In some cases, PTFE has superior resistance to diffusion, for example to the diffusion of automotive fuels, in comparison with all other plastics and rubbers.

#### **Gas/Fluid Cycling**

There are some applications where the fluid passing through the hose turns into a gas, then back into a fluid, then into a gas etc, in a cyclic sequence

This is normally associated with changes in temperature and/or pressure. For complex reasons these conditions are extremely damaging to the hose liner, whatever material it is made from.

For example, hoses are sometimes used to pass steam, water, steam etc into rubber moulding presses, in order to heat the mould, then rapidly cool it before reheating in the next cycle. Hoses of all types fail rapidly in such an application and PTFE lined hoses are no exception.

Please contact Aflex Hose for further information if these conditions apply.

#### **Connecting Assemblies for Use in Applications**

The lengths of hose assemblies and their configuration in use when connected into the application must always be in accordance with the Hose Configuration information at the end of this product literature.

When being connected for use in applications, the end fittings on hose assemblies must be connected to correct mating parts in the correct way, using the correct tools, spanners, clamps, nuts and bolts etc. The connections must be sufficiently tightened to ensure that the joint is leak free but not be over tightened as this can damage the sealing surfaces, especially with PTFE lined and flared end fittings.

In applications involving the transfer through the hose of expensive or dangerous fluids or gases, the hoses and connections must be pressure tested in situ before being put in to service. This should be done with some harmless media to 1.5 times the maximum working pressure of the hose assembly, as stated in the product literature.

If in doubt please contact Aflex Hose for advice.

#### Special Applications

Aflex Hose PTFE lined hose products are not rated as suitable for use in the following, special applications:

All Radioactive Applications involving high energy radiation, including Gamma radiation (degrades PTFE)

All Medical Implantation Applications

For Aerospace Applications, please contact Aflex for the appropriate hose choice.

#### Silicone-Free Application Requirements

Some applications, particularly paint manufacturing plants, and other specialised applications require that hoses do not include any silicone containing materials in their manufacture (which is possible), or sometimes that hoses are 100% Silicone Free (which may not be possible). Customers or Distributors must identify and define any such requirements in writing on all enquiries/orders.

#### Corroflon and Quality Assurance, Certification, Approvals and Hose Testing

#### **BS EN ISO 9001:2015**

Aflex Hose Ltd are independently assessed and certified to BS EN ISO 9001 Quality Management System by The British Standards Institute (BSI)

#### EN 16643:2016

Corroflon meets the requirements of EN 16643 (C), which include the electrical and electrostatic requirements of hose assemblies.

#### ISO 45001:2018

Aflex Hose Ltd have been successfully assessed to the requirements of ISO 45001, by the British Standards Institution (BSI). By gaining this accreditation Aflex Hose Ltd are demonstrating our commitment to the health and safety of our employees by consistently identifying and controlling risks to health and safety, reducing the potential for accidents, complying to relevant legislation and improving overall awareness throughout the business.

#### ISO 14001:2015

Aflex Hose Ltd have been successfully assessed to the requirements of ISO 14001, by the British Standards Institution (BSI). By gaining this accreditation Aflex Hose Ltd are demonstrating our commitment to reducing our impact on the environment.

#### USP Class VI and ISO 10993-5, 6, 10 & 11 GUIDELINES

Natural and Antistatic PTFE Hose Liners, Platinum Cured Silicone Rubber Covers (White and Clear) and EPDM Rubber Cover (Blue) have been independently tested in accordance with USP protocols and are found to conform to the requirements of USP Class VI Chapter <88>.

Natural and Antistatic PTFE Hose Liners and Platinum Cured Silicone Rubber Covers (White and Clear) have also been tested in accordance with USP protocols and are found to conform to the requirements of USP Class VI <87>, the L929 MEM Elution Test and are considered non-cytotoxic.

#### FDA

The Materials used to manufacture the natural PTFE Tube liner conforms to FDA 21 CFR 177.1550, and the antistatic PTFE liner conforms to FDA 21 CFR 178.3297.

#### Pharmaceutical Manufacturers Approvals

Most of the major pharmaceutical manufacturing companies in the world have audited and/or approved Aflex Hose as a Hose Supplier.

#### **BPSA Leachables and Extractables Testing**

Aflex Hose Natural and Antistatic PTFE Hose Liner Tube has been independently tested in accordance with BPSA recommendations, and found to be satisfactory.

Copies of the Test Report are available for specific assessments to be made.

#### CE Marking (Europe only)

Aflex has been assessed by The British Standards Institution (BSI) and found to comply with the Pressure Equipment Directive 2014/68/EU Conformity Assessment Module D1, approved to CE Mark applicable hose products, accompanied by a Hose Usage Data Sheet, and a Declaration of Conformity.

Attestations of Conformity to ATEX Directive 2014/34/EU (Potentially Explosive Atmospheres) Available for hose assemblies for components used in Gas Zones 1 & 2 and Dust Zones 21 & 22, when applicable.

#### Material Certification to EN10204

Available for all the hose or hose assembly components.

#### Certificates of Conformity to BS EN ISO/IEC 17050 Are available for all products.

#### Hose Testina

Each assembly is pressure tested to 1.5 times maximum working pressure before despatch, and pressure test certificates can be supplied.

#### Fire Resistance to BS5173 Section 103.13 Part 6.2 and 6.3

RC Grade Corroflon hose assemblies are "Fire Resistant". If DRC-300 is added at both ends, the assemblies are upgraded to "Fire Proof".

## HOW TO ORDER CORROFLON HOSE ASSEMBLIES

#### How to Order

The quantity, hose size, liner, braid, cover, protection system, length and fittings must be selected and specified in full.

**<u>EITHER</u>** by a full, written description. The hose grade can be specified by the code initials e.g. "Corroflon AS, SS, RC, DRC-300" defines an antistatic PTFE lined hose with an EPDM rubber cover over a SS braid, with a double rubber cover at both ends.

The quantity, length and fittings can then be written in - e.g. "4 off x 1" bore Corroflon, AS, SS, RC, DRC-300 hose x 3.00 metres long (10ft). Both ends non-lined ANSI 150# S/S Flanges".

#### OR by Part Numbers, as defined on page 12.

Any special requirements relating to the hose construction, or information required on Tags, or Certificates, or special testing of requirements, must be specified in full on the enquiry or purchase order.

#### Selecting the Hose Grade

PTFE Liners include, Standard (GP) or Special Purpose (SP), both available either in natural white PTFE or in black, Antistatic PTFE (AS). There are four types of braid, Grade 304 stainless steel (SS) polypropylene (PB), Hastelloy (HB), PVDF or Kynar (KYB). These are described on pages 13 & 14. Rubber covering and other external protection systems are also available, described on page 15.

A hose grade is specified by using the abbreviations given. For example, Bioflex AS,PB would describe a hose with an anti-static PTFE liner and a polypropylene braid.

**Note:** Most of the sizes of hose and fittings listed in this brochure are available as ex-stock items and are priced accordingly. However, when certain items have not been purchased in the last 12 months, they are no longer held in stock, and are only available to Special Order. Aflex Hose will advise accordingly when enquiries are placed for these items.

#### Selecting the Hose Length (see also pages 35 - 37)

Corroflon hose assemblies are made up to the specific lengths required. The hose length is taken as the length from the sealing face at one end of the hose to the same at the other end. The length tolerance is normally +5% / -0%. Closer tolerances are available to special order.

#### **Corroflon Hose Assembly Length Limitations**

		*Minimum Hose Assembly Length							<u>.</u>	
Nominal Size of Hose		Used S	traight		Minimur	Maximum Hose Assembly Length				
		All Gi	rades	TO, SS, PB,	KYB Grades	RC Grades				
in	mm	in	mm	in	mm	in	mm	ft	mtrs	
1/2	15	3	75	2.36	60	3.54	90	100	30	
3/4	20	3	75	3.19	81	4.72	120	100	30	
1	25	3	75	4.33	110	6.50	165	100	30	
1 <sup>1</sup> /4	32	3	75	5.08	129	7.64	194	100	30	
11/2	40	3	75	6.22	158	9.29	236	100	30	
2	50	3	75	8.66	220	12.99	330	100	30	
2 <sup>1</sup> / <sub>2</sub>	65	4	100	11.02	280	16.54	420	65	20	
3	80	4	100	14.25	362	21.34	542	65	20	
4	100	12	300	18.58	472	27.83	707	32	10	
6	150	12	300	37.13	943	55.67	1414	13	4	

\* Listed minimum lengths are for the Corroflon Hose only, and **DO NOT INCLUDE THE LENGTHS OF THE FITTINGS AT EACH END**. These must be found from the end fitting pages and added to calculate the minimum length of the hose assembly. Used straight with fittings in line. Only minimal vibration permitted.

#### Selecting the End Fittings

Corroflon is available with a range of 'standard' end fittings (described on pages 17-30), both integral PTFE lined and non-lined

#### Stainless Steel End Fitting Materials

Non-Lined Spigots - are all made from Grade 316L SS

PTFE Lined Spigots - are all made from Grade 316L or Grade 316C SS

**Cam and Groove Female Fittings** - are made from Grade 316C SS (Body) and 316L SS (Spigot)

Swivelling Nuts and Flanges - are all made from Grade 304 SS

**Ferrules** - most ferrules are made from Grade 304 SS, except some are made from Grade 316L SS - consult Aflex Hose if necessary.

The equivalent specification for the different Grades of Stainless Steel are listed below:

Grade	BS - British Standard	AISI - American Standard or C = Casting Grade	EN - European Norm
316L SS	BS 316 S11	AISI 316 L	EN 1.4404
316C SS	BS 316 C16	CF8M	EN 1.4408
304 SS	BS 304 S15	AISI 304	EN 1.4301

#### Conditions of Sale

Corroflon hose and hose assemblies are only supplied on the basis that the customer has read and accepted the Conditions of Sale as given at the end of this brochure and on the Aflex Hose website.

#### **CORROFLON** EN 16643 HOSE ASSEMBLY ELECTRICAL PROPERTY GRADES

The hose assembly electrical property grades and electrical resistance limits are defined within EN 16643 and tested in accordance with BS EN ISO 8031. Aflex Hose electrically conductive (**EC**) assemblies are defined in EN 16643 as *electrically bonded* and given the symbol **M**. M-grade assemblies exhibit a maximum electrical resistance of 100 $\Omega$  between end fittings. Aflex Hose anti-static (**AS**) PTFE liners and rubber covers are termed *static dissipative* within EN 16643 and given the symbol **Q** followed by letters that specify either the liner, cover or both; L=liner, C=cover, **CL**= cover & liner.  $\Omega$ -grade covers or liners exhibit an electrical resistance of 10<sup>3</sup>-10<sup>8</sup> $\Omega$ .

The table below identifies each EN 16643 electrical grade for a hose assembly along with a brief description and example assembly configuration.

EN16643 Electrical Grade For Hose Assembly	EN16643 Description	Example Hose Assembly
Grade M	Electrically bonded without static-dissipative lining or cover	CFLN/GP SS SI Ends ASA150 Lined CFLN/GP TO Ends JIC female
M/Ω-L	Electrically bonded and static-dissipative lining	CFLN/AS SS SI Ends ASA150 Lined CFLN/AS TO Ends JIC female
M/Ω-C	Electrically bonded and static-dissipative cover	CFLN/GP SS RC Ends ASA150 Lined
M/Ω-CL	Electrically bonded and static-dissipative cover and lining	CFLN/AS SS RC Ends ASA150 Lined
I	Electrically insulated (no electrical bonding AND no static-dissipative layers)	CFLN/GP PB No helix Ends ASA150 Lined
Ω-L	Static dissipative lining without electrical bonding	CFLN/AS TO Ends ASA150 Lined CFLN/AS SS Ends ASA150 PP spigot and flange
Ω-C	Static dissipative cover without electrical bonding	CFLN/GP SS RC Ends ASA150 PP spigot and flange
Ω-CL	Static dissipative cover and lining without electrical bonding	CFLN/AS SS RC Ends ASA150 PP spigot and flange

## **CORROFLON HOSE ASSEMBLY PART NUMBER SYSTEM**

If required, Corroflon Hose Assembly can be defined by an individual Part Number, made up of 7 entries as below:

1	Hose Size	Size Part No.
	1/2"	08
	3/4"	12
	1"	16
	11/4"	20
	11/2"	24
	2"	32
	2 <sup>1</sup> /2"	40
	3"	48
	4"	64
	6"	96

-	
4	<u> </u>
-	

 
 Hose Type
 Type Part No.

 Corroflon GP (Natural PTFE Liner)
 CFLN/GP

 Corroflon AS (Antistatic PTFE Liner)
 CFLN/AS

Braid and Cover	
Tube Only	то
Stainless Steel Braid	SS
Polypropylene Braid	PB
Hastelloy Braid	HB
Kynar (PVDF) Braid	KYB
Black EPDM Rubber Cover (on SS)	RC
Transparent Silicone Rubber (on SS)	SI

Л

No External Protection System	00
SS Wire Protection Coil	PC
Rubber Anti-Scuff Rings	SR
'Safeguard' HDPE Spiral Wrap	SG

External Protection Systems

5

The overall hose length between the sealing faces at each end is given as the <u>Length Part No</u> either in decimal Metres followed by 'm' or inches followed by 'm'

Length

6	Assembled End Fitting Description * All Components in Stainless Steel	End Fitting Part No.
&	JIC Female	02
7	Fixed Male Pipe, NPT Thread	03
	Fixed Male Pipe, BSPT Thread	03/B
	Fixed Female Pipe, NPT Thread	06
	JIC-to-NPT Male Union	08
	JIC-to-Female Union	08F
	Straight Sanitary Tri Clamp, 1.984" Diameter	
	0.870" Exit Diameter (Standard) 1.370" Exit Diameter (Step Up)	10 10/S
	Straight Mini Sanitary Tri Clamp, 0.984" Diameter	11
	0.370" Exit Diameter (Standard) 0.625" Exit Diameter (Step-Up)	11/S
	*ANSI 150# Swivelling Flange Non-Lined	12
	DIN PN 10/16 Swivelling Flange Non-Lined	12/PN
	*ANSI 150# Swivelling Flange, PTFE Lined	12L
	DIN PN 10/16 Swivelling Flange, PTFE Lined	12L/PN
	Cam and Groove, Locking Arm Swivelling Female, Non-Lined	16
	Cam and Groove, Locking Arm Female, PTFE Lined	16L
	Cam and Groove Male, Non-Lined	17
	Cam and Groove, Male PTFE Lined	17L
	DIN 11851 Female, PTFE Lined	23L
	DIN 11851 Male, PTFE Lined	24L
	SMS Female, PTFE Lined	26L
	RJT Female, Non-Lined	27
	BSPP Cone Seat Female	33
	BSP Lug Nut Female	34

Notes - For Flange only: Add '/ZP' for Carbon Steel Zinc Plated, or add '/EC' for Epoxy coated

Elbows: For all types of Elbow fittings add '/90°' for 90° elbows

Triclamps: For 'Hot Formed' PTFE Lined Triclamps add '/HF'

#### Additional Requirements:

- Any additional requirements which are not included in the Part Number must be written out in full in the Order, including any special labelling or colour coding.

- if one of the rubber end protection systems is required, for one or both ends, please define the requirement in writing in addition to the Part Number

#### Example:

A 3/4" bore Corroflon GP, RC Hose Assembly with an Antistatic PTFE Liner and an outer Safegard Sleeve with:

End (1) - a 3/4" ANSI 150# Swivel Flange, PTFE Lined

End (2) - a Cam and Groove Swivelling Female, PTFE Lined

and a Length of - 4ft 6 inches

Hose Assembly Part No. =	12 -	CFLN/AS	- RC -	SG	- 54in	- 12L -	16L
Entry No.	1	2	3	4	5	6	7

## **CORROFLON HOSE LINERS**

#### **GP - General Purpose Liner**



#### Purpose

Corroflon GP, SS is the general purpose grade of hose and has been carefully designed to satisfy the widest range of application requirements.

#### **Design & Approvals**

The hose liner is manufactured from hose quality grade PTFE conforming to FDA requirements 21 CFR 177.1550 extruded into tube and helically convoluted. It also includes a heavy gauge Grade 304 stainless steel reinforcing wire helically wound into the external root of the convolutions to strengthen the convoluted shape. The braid is high tensile grade 304 stainless steel wire braid to give maximum protection to the hose against internal pressure and external abrasion.

Corroflon GP hose liner tube also conforms to USP Class VI at normal temperatures and at  $121^{\circ}C$  ( $250^{\circ}F$ ), see page 9.

#### **SP - Special Purpose Liner**



#### Purpose

For applications requiring a higher temperature/pressure rating, greater flexibility and improved kink and crush resistance. Also for applications requiring vacuum resistance to -0.9bar for hose sizes larger than 2".

#### Design

The convolutions are closer together, yielding greater radial strength to the hose design.

#### **Design & Approvals**

As for Corroflon GP, except that the maximum working pressure for wire braided grades is increased by 25%, the weight per metre is increased by 30%, the actual through bore is reduced by 1/s'' (3mm), the maximum continuous length is reduced by 50%, the minimum bend radius is reduced by 25% and the angle of cleanability is <80°.

Available as SP (Natural) and SP, AS (Antistatic) Grades.

/B C Notes - For Fi I Elbov Tricla

#### **AS - Anti-Static PTFE Liner**



#### Purpose

Corroflon AS grade is an essential requirement in applications where there is the risk of an electrostatic charge build-up on the inside surface of the PTFE tube which may then discharge through the tube wall. Media passing through which create such a risk are fluids which have a Conductance of less than  $10^{-8}$  S/m (Siemens per Metre), or  $10^4$  pS/m such as fuels, solvents, freons, some WFI (ultra-pure "Water for Injection") and non-polar organics which are being transferred at a medium to high flow velocity.

All twin or multi phase media, and any non-mixing media, such as powder in air, or water droplets in steam, in gases or in oil, also colloidal fluids constitute a particular hazard for static charge generation, and **always** require grade AS.

A typical example involves cleaning systems which create a twin phase mixture passing through the hose at high velocity, such as WFI water purged out with air or nitrogen.

If in doubt, consult Aflex Hose.

#### **Design & Approvals**

Corroflon AS grade has an anti-static PTFE liner manufactured from FDA 21 CFR 177.1550 approved PTFE, and less than 2.5% of "high purity" Carbon Black material to FDA requirement 21 CFR 178.3297 and European Commission Directive 2007/19/EC. The carbon is encapsulated by the PTFE, and in normal, non-abrasive applications will not come loose to contaminate any fluid passing through. (This has been confirmed by Extractables and Leachables Tests in accordance with BPSA recommendations).

Corroflon AS hose liner tube also conforms to USP Class VI at normal temperatures and at  $121^{\circ}C$  ( $250^{\circ}F$ ), see page 9.

#### Antistatic Hose Assemblies

When "AS" (Antistatic) grade hose is specified, then the hose or hose assembly supplied will be tested in accordance with EN ISO 8031 and meet the Antistatic requirements of EN 16643. This requires, for an antistatic liner or antistatic cover, that the resistance between an appropriately placed foam electrode and a metallic end fitting will be between  $10^3$  to  $10^8$  Ohms per assembly. For hose assemblies which meet these requirements an appropriate Grade " $\Omega$ " marking is applied in accordance with EN 16643.

**Note:** When in service, at least one end fitting must be connected to earth, to permit dissipation of the static charge from the end fitting.

## **CORROFLON HOSE BRAIDS**


#### SS - Stainless Steel Braid



#### Purpose

Stainless Steel braided hose is the general purpose product, and can be used in applications involving high temperatures and working pressures. High tensile AISI 304 stainless steel wire is used, to give maximum pressure resistance and external protection to the hose.

#### **PB - Polypropylene Braid**



#### Purpose

Polypropylene braided hose is often preferred to SS in applications involving frequent handling and movement of the hose, and where temperatures are within the range -30°C to +100°C (-22°F to +212°F). PB braid is lighter in weight, and any broken strands will not cut the operator's hands. In addition, PB braid is not prone to "chloride stress corrosion", and has generally good chemical resistance.

NOTE: Prolonged exposure to sunlight eventually results in UV degradation of PB braid

#### KYB - Kynar Braid (Polyvinylidene Fluoride Monofilament)



#### Purpose

Kynar Braid is used in the same application as Hastelloy Braid, but only in applications where the reduced pressure ratings of KYB as listed are acceptable. A Safegard Sleeve is always recommended. Monel or Hastelloy wire should be used.

Full details about the applications should be given to Aflex Hose for evaluation and recommendations.

#### TO - Tube Only (no braid)



#### Purpose

TO grade hose (available in both GP and AS) is a lightweight hose, used in applications where working pressures are low and where there is no need for the physical protection offered by an external braid.

#### HB - Hastelloy Braid (C276 grade)



#### Purpose

Hastelloy Wire Braid is used instead of SS where severe chemical corrosion conditions exist around the outside of the hose. The most usual way in which this can happen is when Chlorine, Bromine, Hydrogen Fluoride, Hydrogen Chloride or Phosgene are being transferred. Diffusion of trace quantities of such fluids or gases through the PTFE liner can lead to atmospherically wetted halogen chemicals attacking the braid material, in which case the Hastelloy Braid would be resistant up to 60°C (140°F) maximum. This should only be used, however, in conjunction with a Monel or Hastelloy Helix Wire.

Full details about the applications should be given to Aflex Hose for evaluation and recommendations.

#### Specifications

Same as for SS on Page 7, except the Burst Pressures and the Maximum Working Pressures are both reduced to 80% of the SS pressures listed.

Also, the sizes range is restricted, from 1/2" up to 2" bore only.


#### SPECIAL NOTE:

**EC - Electrical Continuity** (Also known as "Electrically Bonded")

The requirements for this are specified in the German Document BRG 132 and EN 16643, when tested in accordance with EN ISO 8031, which requires that the resistance between end fittings shall be <10<sup>2</sup> Ohms per assembly. For hose assemblies which meet this requirement a Grade "M" marking is applied in accordance with EN 16643.

## **CORROFLON RUBBER COVERS**

#### RC - EPDM Rubber Covered - Antistatic and Fire Proof Black Rubber Cover



#### Purpose

For the most rugged applications where the hose may be subjected to rough treatment and severe external abrasion. Also for hygienic applications, where the external cleanability of the hose is of prime importance and in applications where the hose is required to be Fire Proof, or to have an Antistatic cover.

#### Design

An SS braided hose has a black, antistatic EPDM external rubber cover extruded directly onto the braid to produce a super-smooth external surface finish. Sizes above 2" bore are hand wrapped post assembly.

EPDM has excellent chemical resistance, and the hose has a temperature range from -40°C, -40°F up to +150°C, +302°F.

#### Fireproof

As well as providing an Antistatic cover, Corroflon RC hose is also Fire Proof in accordance with Specification BS5173 Section 103.13 part 6.2 (Fireproof). This specification calls for an 1100°C (2012°F) flame to be applied to the hose at minimum bend radius, maximum operating pressure (water), and one end fitting under vibration. The hose must withstand at least 15 minutes without leakage.

Hose assemblies are Fire Resistant, but can be rendered Fire Proof by the addition of DRC-300 at both ends - see below.

Corroflon RC hose meets the requirements of German Safety Regulation TRBF 131/2 and EN 16643 flame resistance.

#### Antistatic

Corroflon RC hose is antistatic (AS) in accordance with EN 16643 limits and tested in accordance with EN ISO 8031.

#### SI - Silicone Rubber Cover



#### Purpose

As for RC hose, but where the hose may be required to withstand temperatures from -73°C, -100°F up to +224°C, +435°F. SI grade hose is semi-transparent, allowing visual monitoring of the braid.

#### Design

An SS braided hose assembly has an external smooth finish, platinum cured silicone rubber cover extruded (>50 metres) or hand-wrapped (<50 metres), and vulcanised directly onto the braid.

#### Specifications

The Silicone rubber cover has been tested and conforms to the requirements of USP Class VI, see page 9.

#### RC-300 - Rubber Covered 300mm at End



#### Purpose

In applications where excessive flexing of the hose at the end fitting occurs, it is sometimes necessary to 'stiffen' the hose in this area, to prevent kinking.

#### Desian

A layer of rubber is hand-wrapped and vulcanised directly to the ferrule, and 300mm (12 inch) along the hose from the fitting. This can be done either on an SS braided hose (RC-300 or SI-300) or on a rubber covered hose as a 300mm (12 inch) long double layer of rubber at the end (DRC-300 or DSI-300).

## **CORROFLON EXTERNAL PROTECTION SYSTEMS**

#### **SG - Safegard Protection Sleeve**



#### Purpose

To protect the hose against external abrasion and mechanical damage. For use in applications where maximum external protection is required with minimum extra hose weight. Particularly useful with PB or KYB hose, where a rubber cover is not an option.

#### Design

A lightweight black, HDPE (High Density Poly Ethylene) strip spirally wound around the outside of the hose over its whole length, secured to each end fitting by crimping under a SS ferrule.

#### Limitations

Safegard is applicable to all hose types and all hose sizes from 1/2" up to 4".

Safegard is limited to use within a temperature range from -40°C (-40°F) up to +110°C (230°F). Internal fluid temperatures up to 140°C (284°F) are acceptable, when external temperatures are ambient.

The minimum hose assembly length must be doubled, if Safegard is being used and the maximum assembly lengths for all sizes are capped at 20 metres (65 feet).

The other hose usage limitation specifications are not altered by the addition of Safegard.

Safegard is available with anti-static properties and complies with the requirements of a static-dissipative cover within EN 16643 (see page 11 for further information). Request details upon enquiry.

#### SR - Scuff Rings



#### Purpose

For medium duty applications where the hose requires some protection against abrasion when dragged over the ground, but where a full rubber cover would be too heavy and cumbersome. Also for PB and KYB braided hose, which cannot be Rubber Covered.

#### Design

Specially moulded abrasion resistant rubber scuff rings are placed every half metre along the hose.

#### Limitations

Available for hose sizes 1" (25mm) to 2" (50mm) only. The operating temperature should not exceed  $140^{\circ}C$  (284°F) (internal).

#### PC - Protection Coil



#### Purpose

For applications where the hose requires protection against abrasion when dragged over the ground, but where any rubber reinforcement is not permissible due to temperature, chemicals etc.

#### Design

A stainless steel wire helix is wound onto the braid and welded to the ferrules at each end.

#### Limitations

Available for all sizes and grades of hose, including rubber covered.

The maximum assembly lengths for all sizes are capped at 20 metres (65 feet).

#### Specifications

As for the relevant hose grade.


## **CORROFLON NON LINED SWIVEL FLANGE FITTINGS**

#### Flange Specifications

- ANSI B16.5 (also ASME B16.5) Class 150# and 300#
- \*DIN PN10/16/40 up to 2" size, PN10/16 from 2<sup>1</sup>/<sub>2</sub>" up to 6" size
- JIS 10K
- Other Pressure Ratings and Flange Specifications are also available.
   \*The dimensions for flanges to the different pressure ratings are identical, so they are inter-changeable.

#### **End Fitting Materials**

- Flanges in Grade 304 SS
- Flange Retainers in Grade 316L SS
- Ferrules, most in Grade 304 SS, some sizes in Grade 316 SS



The above drawing relates to sizes 1", 11/2", 2"

Nominal	Hose Size	*Fitting L PN1			iameter D 0/16	Fitting Insid	e Diameter I	Weight o	of Fitting
in	mm	in	mm	in	mm	in	mm	Kg	Lbs
1/2	13	2.20	56	1.77	45	0.39	10	0.76	1.69
3/4	20	3.11	79	2.28	58	0.63	16	1.06	2.35
1	25	3.46	88	2.68	68	1.12	28.5	1.36	3.00
1 <sup>1</sup> /4	32	3.98	101	3.07	78	1.02	26	1.72	3.79
1 <sup>1</sup> /2	40	4.69	119	3.46	88	1.69	43.10	2.49	5.50
2	50	4.69	119	4.02	102	2.15	54.5	3.57	7.87
2 <sup>1</sup> / <sub>2</sub>	65	5.20	132	4.80	122	2.24	57	4.20	9.26
3	80	5.28	134	5.43	138	2.64	67	5.68	12.52
4	100	5.51	140	6.22	158	3.50	89	8.42	18.56
6	150	7.00	178	8.35	212	5.51	140	12.30	27.12

\*Fitting Lengths listed are for Corroflon braided only hose grades (SS, PB, HB, KYB). Approximately 33% longer lengths apply to the rubber covered hose grades (RC, SI).


Nominal	Nominal Hose Size		Length A 150	ASA150		Fitting Insid	e Diameter I	Weight o	of Fitting
in	mm	in	mm	in	mm	in	mm	Kg	Lbs
1/2	13	2.13	54	1.37	34.9	0.39	10	0.76	1.69
3/4	20	2.99	76	1.69	42.9	0.63	16	1.06	2.35
1	25	2.95	75	2.00	50.8	0.79	20.24	1.36	3.00
1 <sup>1</sup> /4	32	3.78	96	2.50	63.5	1.02	26	1.72	3.79
1 <sup>1</sup> /2	40	4.25	108	2.87	73.0	1.25	31.75	2.49	5.50
2	50	4.41	112	3.63	92.1	1.75	44.45	3.57	7.87
2 <sup>1</sup> / <sub>2</sub>	65	5.27	134	4.12	104.5	2.24	57	4.20	9.26
3	80	5.43	138	5.00	127.0	2.64	67	5.68	12.52
4	100	5.51	140	6.19	157.2	3.50	89	8.42	18.56
6	150	7.00	178	8.50	215.9	5.51	140	12.30	27.12

#### Alternative Options for Flange Component only:

- Zinc Plated Carbon Steel
- Grade 316 Stainless Steel

#### **Maximum Pressure Ratings**

- ANSI 150# = 16 Bar (230 psi), ANSI 300# = 32 Bar (460 psi)
- DIN PN10 = 10 Bar (145 psi),
- DIN PN16 = 16 Bar (143 psi),DIN PN16 = 16 Bar (230 psi)
- DIN PN40 = 40 Bar (580 psi)



#### The above drawing relates to all other sizes

#### **CORROFLON INTEGRAL PTFE LINED FLANGE FITTINGS** & 'STEP-UP' DESIGN

#### Flange Specifications

- ANSI B16.5 (also ASME B16.5) Class 150# and 300#
- \*DIN PN10/16/40 up to 2" size, PN10/16 from 2<sup>1</sup>/<sub>2</sub>" up to 6" size • JIS 10K
- · Other Pressure Ratings and Flange Specifications are also available.
- \*The dimensions for flanges to the different pressure ratings are identical, so they are inter-changeable.

#### **End Fitting Materials**

- Flanges in Grade 304 SS
- Flange Retainers in Grade 316L SS
- Ferrules, most in Grade 304 SS, some sizes in Grade 316 SS

#### Integral PTFE Lined Swivel Flange Fittings

#### Alternative Options for Flange Component only:

- Zinc Plated Carbon Steel
- Grade 316 Stainless Steel

#### Maximum Pressure Ratings

- ANSI 150# = 16 Bar (230 psi), ANSI 300# = 32 Bar (460 psi)
- DIN PN10 = 10 Bar (145 psi),
- DIN PN16 = 16 Bar (230 psi)
- DIN PN40 = 40 Bar (580 psi)

#### 90° Elbow Flange Fittings (see page 30)

• 90° Elbow Integral PTFE lined Flange Fittings are available for 1", 1<sup>1</sup>/<sub>2</sub>" & 2".

## **CORROFLON FEMALE CAM & GROOVE FITTINGS PTFE LINED & NON-LINED**

#### **End Fitting Specifications**

• Generally in accordance with A-A-59326 (replaces MIL-C-27487) and EN14420-1 (replaces DIN 2828), and all are fully interchangeable

#### **End Fitting Materials**


- Spigot in Grade 316L SS
- Body in Grade 316C SS
- Ferrules, most in Grade 304 SS, some sizes in Grade 316L SS
- Standard Gasket is Buna N (Nitrile) Rubber.
- FEP encapsulated Silicone Rubber Gaskets also available

#### **Temperature & Pressure Ratings**

- When used with a Buna N Gasket all sizes up to 16 Bar (230 psi) and up to a maximum temperature of  $65^{\circ}C$  (149<sup>°</sup>F)
- When used with FEP, Fluoro Rubber or other encapsulated gaskets

#### Swivelling, Locking Arm Female Cam & Groove Fittings - Non-Lined





Nominal	Hose Size		Length A \150		Length A 0/16	Flared Diameter D ASA150	Flared Diameter D PN10/16	Recommended Bolt Tightening Torques		Weight of Fitting	
in	mm	in	mm	in	mm	mm	mm	ft.lbs	Nm	Kg	Lbs
<sup>1</sup> / <sub>2</sub>	15	2.09	53	2.09	53	**32.0	**32.0	8	10.79	0.54	1.19
3/4	20	2.28	58	2.34	59.5	43.0	**50.0	8	10.79	0.88	1.94
1	25	2.28	58	2.36	60	50.8	**63.5	10	13.73	0.96	2.11
1 <sup>1</sup> /4	32	2.48	63	2.52	64	63.0	78.0	12	16.67	1.36	2.99
1 <sup>1</sup> /2	40	2.40	61	2.50	63.5	73.0	88.0	15	20.59	1.75	3.85
2	50	2.52	64	2.62	66.5	92.0	102.0	25	34.32	2.70	5.94
2 <sup>1</sup> / <sub>2</sub>	65	3.11	79	3.19	81	105.0	122.0	30	41.18	4.00	8.80
3	80	3.11	79	3.11	79	127.0	**127.0	40	53.94	5.00	11.00
4	100	5.20	132	5.20	132	158.0	158.0	40	53.94	7.00	15.40
6	150	3.66	93	3.66	93	213.0	213.0	50	67.67	13.00	29.00

\*Fitting Lengths listed are for Corroflon braided only hose grades (SS, PB, HB, KYB). Approximately 33% longer lengths apply to the rubber covered hose grades (RC, SI). \*\*The listed Flare Diameters are not all full size due to limitations on PTFE flare diameters.

PLEASE NOTE THE TABLE ABOVE IS CURRENTLY UNDER REVIEW.

'Step-Up' PTFE Lined Flange Fitting Design for Corroflon Hose

#### Adapting for Different Flange Sizes


#### To fit larger than nominal flange sizes

It may be necessary to fit a larger than nominal flange size to the hose - for example, 3" flange fitted to one end of a 2" hose - in which case it may also be necessary to increase the diameter of the sealing face to the correct size for the larger flange. This can be achieved by means of a flange adaptor as shown.

#### To fit smaller than nominal flange sizes

Within limits, it is also possible to make up an assembly with a flange one size smaller than the nominal size. The smaller flange is bored out and fitted to the larger hose and, if necessary, the flared diameter is reduced to suit.

Consult the supplier if a different flange size is required.



		1
 11	6	
	0	
		Com Sloo

Nominal	Hose Size	*Fitting I	ength A		nside Diameter D	Fitting Insid	e Diameter I	Weight o	of Fitting	
in	mm	in	mm	in	mm	in	mm	Kg	Lbs	
3/4	20	3.11	79	1.26	32	0.63	15.9	0.40	0.88	
1	25	3.07	78	1.46	37	0.75	19.1	0.51	1.12	
1 <sup>1</sup> /2	40	4.13	105	2.13	54	1.25	31.8	0.88	1.94	
2	50	4.25	108	2.52	64	1.75	44.5	1.15	2.53	
2 <sup>1</sup> / <sub>2</sub>	65	4.49	114	3.03	77	2.25	57.2	1.41	3.10	
3	80	4.61	117	3.62	92	2.63	66.7	1.89	4.17	

#### Fixed, Locking Arm Female Cam & Groove Fittings - Integral PTFE Lined



Nominal I	Hose Size	*Fitting L	ength A		nside Diameter D	Fitting Inside Diameter I		Weight of Fitting	
in	mm	in	mm	in	mm	in	mm	Kg	Lbs
3/4	20	2.48	63	1.26	32	0.70	17.8	0.39	0.86
1	25	2.40	61	1.46	37	0.95	24.1	0.50	1.10
1 <sup>1</sup> /2	40	2.56	65	2.13	54	1.44	36.7	0.86	1.89
2	50	2.56	65	2.52	64	1.94	49.3	1.10	2.42

\*Fitting Lengths listed are for Corroflon braided only hose grades (SS, PB, HB, KYB). Approximately 33% longer lengths apply to the rubber covered hose grades (RC, SI).


all sizes up to 10 Bar (145 psi) and up to a maximum temperature of 204°C (400°F)


#### 90° Elbow Cam & Groove Fittings (PTFE Lined only)

• 90° Elbow Integral PTFE lined Cam & Groove Fittings are available for sizes 1", 1<sup>1</sup>/<sub>2</sub>" & 2" - see page 30

#### Notes: For Integral PTFE Lined Fittings Only

- FEP Gaskets require higher clamping forces to flatten the Seal and make the joint. This is made easier by "pre-setting" these gaskets by clamping Polypropylene Cam Male Inserts to the assembled fittings, which must then be kept in place during storage, until use.
- Any Customer's Own "Special" Gaskets must be pre-supplied to Aflex for special assembly and testing of hose assemblies, to ensure suitability





## **CORROFLON MALE CAM & GROOVE FITTINGS** & PTFE LINED FLANGE ADAPTORS


#### **End Fitting Specifications**

 Generally in accordance with A-A-59326 (replaces MIL-C-27487) and EN14420-1 (replaces DIN 2828), and all are fully interchangeable

#### **End Fitting Materials**

- Spigot in Grade 316L SS
- Ferrules, most in Grade 304 SS, some sizes in Grade 316 SS
- Adaptor Flange Only in Grade 304 SS


#### Non-Lined Cam & Groove Male Fitting



#### Temperature & Pressure Ratings

 Temperature and pressure determined by the type of gasket in the Female connecting component


> Integral PTFE Lined Cam & Groove Male Fitting



Nominal I	Hose Size	ø	D	*Fitting I	Fitting Length A Non-Lined PTFE Lined Weight of Inside Diameter I Inside Diameter B				of Fitting		
in	mm	in	mm	in	mm	in	mm	in	mm	Kg	Lbs
<sup>3</sup> /4	20	1.26	32	3.38	86	0.63	15.88	0.70	17.78	0.40	0.88
1	25	1.46	37	3.66	93	0.80	20.24	0.88	22.35	0.49	1.08
1 <sup>1</sup> /2	40	2.13	54	5.00	127	1.25	31.75	1.12	28.50	0.81	1.78
2	50	2.52	64	5.67	144	1.75	44.45	1.77	44.96	1.05	2.31

\*Fitting Lengths listed are for Corroflon braided only hose grades (SS, PB, HB, KYB). Approximately 33% longer lengths apply to the rubber covered hose grades (RC, SI).

#### PTFE Lined Male Cam & Groove X Flange Adaptors



**Note:** Other Flange Specifications and Pressure Ratings are also available. Non-Lined adaptors and Female Cam and Groove X Flange Adaptors are also available, to special order.



Cam / Ada Siz	ptor	Flange Size & Specification	ø	D	,	4	I		Weight of Fitting	
in	mm		in	mm	in	mm	in	mm	Kg	Lbs
1	25	1" ANSI/1507	2.00	50	41/8	105	0.84	21	1.246	2.75
1	25	DN25/PN16	2.58	64	41/8	105	0.84	21	1.538	3.39
1 <sup>1</sup> /2	40	11/2" ANSI/1507	2.87	73	4 <sup>3</sup> /8	118	1.35	34	2.228	4.92
1 <sup>1</sup> /2	40	DN40/PN16	3.47	88	4 <sup>3</sup> /8	118	1.35	34	2.753	6.07
2	50	2" ANSI/1507	3.63	92	4 <sup>3</sup> /8	118	1.69	43	3.359	7.40
2	50	DN50/PN16	4.02	102	4 <sup>3</sup> /8	118	1.69	43	3.714	8.19

## **CORROFLON MINI-SANITARY & SANITARY TRICLOVER** PTFE LINED FITTINGS

#### End Fitting Specifications

- ASME BPE-a-2007 (USA)
- DIN32676 Type C (Europe, DN Sizes)


#### **Temperature and Pressure Ratings**

- Pressures up to 16 Bar (230 psi)
- Temperatures up to 180°C (356°F)
- Higher Pressures & Temperatures possible with Special Clamps and appropriate Seals

	ninal e Size		ninal Size	Fitting Outlet		
in	mm	in	mm	in	mm	
1/2	15	1/2	12.7	<sup>3</sup> /8	9.4	
1	25	1	25.4	<sup>7</sup> /8	22.1	
1 <sup>1</sup> /2	40	1 <sup>1</sup> /2	38.1	1³/8	34.8	
2	50	2	50.8	17/8	47.5	
2 <sup>1</sup> / <sub>2</sub>	65	2 <sup>1</sup> / <sub>2</sub>	63.4	2 <sup>3</sup> /8	60.2	
3	80	3	76.1	27/8	72.9	
4	100	4	101.6	33/4	96	

\*Fitting Lengths listed are for Corroflon braided only hose grades (SS, PB, HB, KYB). Approximately 33% longer lengths apply to the rubber covered hose grades (RC, SI).

4.680



#### **End Fitting Materials**

119

- Fittings in Grade 316L SS (=BS 316 S11 = EN 1.4404
- Ferrules, most in Grade 304 SS, some sizes in Grade 316L SS

#### 90° Elbows

 PTFE Lined 90°elbow fittings are available for some sizes and grades - see page 30

4.88

					•
Flange Di	iameter D	*Length o	f Fitting A	Weight o	of Fitting
in	mm	in	mm	Kg	Lbs
0.984	25.0	1.96	50	0.075	0.17
1.984	50.5	2.36	60	0.294	0.650
1.984	50.5	2.48	63	0.393	0.866
2.516	64.0	2.60	66	0.523	1.150
3.050	77.5	3.22	82	0.752	1.660
3.580	91.0	3.22	82	1.021	2.250

124

2.269

5.000

#### **CORROFLON MINI-SANITARY & SANITARY TRICLOVER** NON-LINED FITTINGS

#### **End Fitting Specifications**

- ASME BPE-a-2007 (USA)
- DIN32676 (Europe, DN Sizes)
- ISO 1127 (Europe) (Non Standard, Specials Only)

#### **Temperature and Pressure Ratings**

For Standard Clamp and Standard (EPDM) Gasket

- Pressures up to 16 Bar (230 psi)
- Temperatures up to 120°C (250°F)
- Higher Pressures & Temperatures possible with Special Clamps and Gaskets

#### **End Fitting Materials**

+ Fittings in AISI 316L = EN 1.4404 = BS 316 S11. Internal Bores all Electropolished to <15 $\mu$ in Ra (<0.375 $\mu$  mtr)

• Ferrules, most in Grade 304 SS, some sizes in Grade 316L SS

#### Outlet Diameters (Inch pipe sizes only)


 The outlet diameters as listed are in accordance with BS4825. The ASME specification, however, requires these diameters to be 0.005" (0.125mm) less in each case. An Outlet Diameter tolerance of +0.000 -0.005" has therefore been applied, so that the same fitting satisfies requirements of both specifications

ØI ØD


#### DIN 32676 SERIES A (DIN) \*Fitting Flange Outlet **Nominal Hose Size Diameter** D Diameter Length A in METRIC DN in mm in mm in mm 2.016 51.2 1/2 15 1.339 34 0.630 16 20 1.339 0.787 20 2.945 74.8 3⁄4 34 26 2.972 1 25 1.988 50.5 1.024 75.5 1 1⁄4 32 3.929 99.8 32 1.988 50.5 1.260 1 ½ 40 1.988 50.5 1.496 38 4.000 101.6 50 2 50 2.520 64 1.969 4.248 107.9 2 1/2 65 3.583 91 2.598 66 4.370 111.0 80 4.173 106 3.189 81 5.469 138.9 3


		[	DIN 32676 SE	RIES B (ISO)			
In	METRIC DN	in	mm	in	mm	in	mm
1/2	21.3	1.988	50.5	0.713	18.1	1.996	50.7
3⁄4	26.9	1.988	50.5	0.933	23.7	2.846	72.3
1	33.7	1.988	50.5	1.169	29.7	2.972	75.5
1 1⁄4	42.4	2.520	64	1.512	38.4	3.547	90.1
1 1⁄2	48.3	2.520	64	1.744	44.3	4.000	101.6
2	60.3	3.051	77.5	2.217	56.3	4.134	105.0
2 1/2	76.1	3.583	91	2.839	72.1	4.744	120.5
3	88.9	4.173	106	3.319	84.3	5.079	129.0

	DIN	32676 SER	IES C (ASME	BPE)		
in	in	mm	in	mm	in	mm
1/2	0.984	25.0	0.370	9.4	1.744	44.3
3⁄4	0.984	25.0	0.620	15.75	3.004	76.3
1	1.988	50.5	0.870	22.1	2.972	75.5
1 1⁄2	1.988	50.5	1.370	34.8	4.000	101.6
2	2.520	64	1.870	47.5	4.252	108.0
2 1/2	3.051	77.5	2.370	60.2	4.370	111.0
3	3.583	91	2.870	72.9	4.882	124.0




# - A





## CORROFLON 90° ELBOW TRICLOVER FITTINGS SANITARY & MINI SANITARY



**End Fitting Specifications** 

- BS4825 Pt 3
- ASME BPE-a
- Others to special order

#### Temperature and Pressure Ratings

For Standard Clamp and Standard (EPDM) Gasket

- Pressures up to 16 Bar (230 psi)
- Temperatures up to 120°C (250°F)
- Higher Pressures & Temperatures possible with Special Clamps and Gaskets

	ninal Size		Line to End A		Centre Line to Face B		Flange Diameter D		Outlet Diameter I		Weight of Fitting	
in	mm	in	mm	in	mm	in	mm	in	mm	Kg	Lbs	
1/2	13	5.78	147	1.60	41.0	0.984	25.0	<sup>3</sup> /8	9.5	0.137	0.30	
3/4	20	6.41	163	1.60	41.0	0.984	25.0	<sup>5</sup> /8	16.0	0.205	0.45	
1	25	6.53	166	2.00	51.0	1.984	50.5	<sup>7</sup> /8	22.2	0.347	0.77	
1 <sup>1</sup> /2	40	7.99	203	2.75	70.0	1.984	50.5	1 <sup>3</sup> /8	34.9	0.590	1.30	
2	50	9.33	237	3.50	88.9	2.519	64.0	17/8	47.6	0.928	2.05	

\*Fitting Lengths listed are for Corroflon braided only hose grades (SS, PB, HB, KYB). Approximately 33% longer lengths apply to the rubber covered hose grades (RC, SI).



#### **End Fitting Materials**

- Fittings in Grade AISI 316L = EN 1.4404 = BS 316 S11
- Internal Bore average 15µin Ra, Electropolished if required
- Ferrules, most in Grade 304 SS, some sizes in Grade 316L SS

#### **Outlet Diameters**

 The outlet diameters as listed are in accordance with BS4825. The ASME specification, however, requires these diameters to be 0.005" (0.125mm) less in each case. An Outlet Diameter tolerance of +0.000 -0.005" has therefore been applied, so that the same fitting satisfies requirements of both specifications

#### **CORROFLON DIN 11851 FITTINGS PTFE LINED & NON-LINED**

#### Description


- DIN 11851 male and female fittings, integrally PTFE lined
- Also available non-lined, up to 4" (100mm), to special order

#### Specification

· Generally to German DIN 11851 specification

 $\ensuremath{\text{NB:}}$  The PTFE lined male fitting is designed to be used without a rubber seal. Please note that when connecting to a PTFE Lined DIN11851 Male, extra spanner tightening of the nut is sometimes required in order to provide a leak free connection

#### PTFE Lined DIN11851 Female Fitting



**End Fitting Materials** 

Ferrules, most in Grade 304 SS, some sizes in Grade 316L SS

- **Temperature and Pressure Ratings**  Sizes up to 1<sup>1</sup>/<sub>2</sub>" MWP = 40 Bar (580 psi) up to 140°C (284°F)
- Sizes 2" to 3" MWP = 25 Bar (360 psi) up to 140°C (284°F) **Except** where the applicable hose pressure ratings are lower (page 5)

#### 90° Elbows


• PTFE Lined 90° elbow fittings are available for some sizes and grades - see page 30


> Length of Fitting A



#### PTFE Lined DIN11851 Male Fitting








Nominal Hose Size		*Fitting Length A (Male)		*Fitting Length A (Female)		Weight of Fitting (Male)		Weight of Fitting (Female)	
in	mm	in	mm	in	mm	Kg	Lbs	Kg	Lbs
3/4	20	2 <sup>3</sup> /8	60	2 <sup>3</sup> /8	60	0.18	0.39	0.22	0.48
1	25	2 <sup>3</sup> /8	60	25/8	67	0.22	0.48	0.36	0.79
1 <sup>1</sup> /4	32	2 <sup>1</sup> / <sub>2</sub>	65	2 <sup>3</sup> /4	70	0.27	0.59	0.47	1.04
1 <sup>1</sup> /2	40	25/8	67	27/8	73	0.33	0.73	0.55	1.21
2	50	25/8	67	27/8	73	0.58	1.28	0.93	2.05
2 <sup>1</sup> /2	65	31/2	89	35/8	92	0.73	1.61	1.31	2.88
3	80	4	100	35/8	92	1.00	2.20	1.57	3.46

\*Fitting Lengths listed are for Corroflon braided only hose grades (SS, PB, HB, KYB). Approximately 33% longer lengths apply to the rubber covered hose grades (RC, SI).

#### Non-Lined DIN11851 Female Fitting

**Description** - DIN11851 Female Fittings, Non-Lined, are available in sizes <sup>3</sup>/<sub>4</sub>", 1", 1<sup>1</sup>/<sub>2</sub>", 2", 2<sup>1</sup>/<sub>2</sub>", 3" and 4". Consult Aflex Hose for details. Materials - Spigots in Grade 1.4571 (AISI 316 Ti), Nuts in Grade 304 SS, Ferrules, most in Grade 304 SS, some in Grade 316 SS



Nominal H	lose Size	ØI		Fitting L	.ength A	Fitting Weight	
in	mm	in	mm	in	mm	Kg	Lbs
1/2	13	48	1.89	16	0.63	0.18	0.40
3/4	20	73	2.87	20	0.79	0.24	0.53
1	25	74	2.91	26	1.02	0.41	0.90
1 <sup>1</sup> /4	32	89	3.50	32	1.26	0.52	1.15
1 <sup>1</sup> /2	40	101	3.98	38	1.50	0.75	1.65
2	50	105	4.13	50	1.97	1.11	2.45

#### **CORROFLON SMS FEMALE FITTINGS - PTFE LINED** & RJT FEMALE FITTINGS - NON-LINED

#### **End Fitting Specifications**

- SMS generally to Swedish SMS1148 specification
- RJT generally to British BS4825 Pt 5 specification

#### **Temperature and Pressure Ratings**

- Pressures up to 10 Bar (150 psi)
- Temperatures up to 150°C (302°F)

#### PTFE Lined SMS Female Fitting



Nominal	Nominal Hose Size		Length A	Outlet	Dia. I	Weight of Fitting	
in	mm	in	mm	in	mm	Kg	Lbs
1	25	3 <sup>1</sup> /8	79	1	25	0.60	1.32
1 <sup>1</sup> /2	40	3 <sup>1</sup> /2	89	1 <sup>1</sup> /2	38	0.98	2.16
2	50	33/4	95	2	50	1.22	2.69
2 <sup>1</sup> / <sub>2</sub>	65	45/8	116	2 <sup>1</sup> / <sub>2</sub>	63	1.549	3.41
3	80	4 <sup>3</sup> / <sub>4</sub>	122	3	75	1.997	4.40

#### **RJT Female Fitting, Non-Lined**



Nominal	Hose Size	*Fitting Length A		Outlet	Dia. I	Weight of Fitting		
in	mm	in	mm	in	mm	Kg	Lbs	
1	25	2.68	68	0.80	20.24	0.27	0.60	
1 <sup>1</sup> /2	40	3.78	96	1.25	31.75	0.49	1.08	
2	50	3.90	99	1.75	44.45	0.67	1.48	
2 <sup>1</sup> / <sub>2</sub>	65	4.09	104	2.25	57.15	0.78	1.72	
3	80	4.21	107	2.63	66.7	0.89	1.96	


\*Fitting Lengths listed are for Corroflon braided only hose grades (SS, PB, HB, KYB). Approximately 33% longer lengths apply to the rubber covered hose grades (RC, SI).


#### **End Fitting Materials**

- Spigots in Grade 316L SS
- Nuts in Grade 304 SS
- Ferrules, most in Grade 304 SS, some sizes in Grade 316L SS

#### 90° Elbows

• PTFE Lined 90° elbow fittings are available for some sizes and grades - see page 30





## **CORROFLON NPT & BSPT FIXED MALE & NPT FIXED FEMALE FITTINGS**

#### **End Fitting Specifications**

Fixed Male NPT or BSPT

- NPT Taper Threads to American National Standard Pipe Taper Thread design to ANSI/AMSE B1.20.1
- BSPT Threads to British Standard Pipe Taper Thread design to BS21 Alternatives - Parallel Threads, Metric Threads and Others

#### **End Fitting Materials**

- Fittings in Grade 316L SS
- Ferrules, most in Grade 304 SS, some sizes in Grade 316L SS
- Alternatives Fittings in Zinc Plated Carbon Steel

## **CORROFLON BSP 60° CONE SEAT FEMALE UNIONS & BSP FLAT SEAT LUG NUT FEMALE FITTINGS**

#### **End Fitting Specifications**

- BSPP Threads to British Standard Pipe Parallel Thread design to BS21, 60° Cone Seat design, or Flat Seat
- Available in sizes up to 4"

Alternatives - Cone Seat Female Union Fittings can be supplied with a BSPP/BSPT Taper Male Adaptor if required

#### BSP 60° Cone Seat Female Union Fitting



Nominal	Hose Size	NPT or BSPT Thread Size	*Fitting Length A		Fitting Inside Diameter I		Weight of Fitting	
in	mm	in	in	mm	in	mm	Kg	Lbs
1/2	13	1/2	2 <sup>1</sup> / <sub>2</sub>	63	0.37	9.35	0.11	0.25
3/4	20	3/4	31/2	89	0.63	15.88	0.15	0.34
1	25	1	31/2	89	0.80	20.24	0.24	0.53
1 <sup>1</sup> /2	40	1 <sup>1</sup> /2	37/8	98	1.25	31.75	0.72	1.59
2	50	2	4	100	1.75	44.45	0.99	2.19


#### **BSP Flat Face Lug Nut Female Fitting**



Nominal Hose Size		BSPT Thread Size	*Fitting Length A		Fitting Inside Diameter I		Weight of Fitting	
in	mm	in	in	mm	in	mm	Kg	Lbs
1	25	1	2.72	69	0.80	20.24	0.25	0.55
1 <sup>1</sup> /2	40	1 <sup>1</sup> /2	3.78	96	1.25	31.75	0.61	1.33
2	50	2	3.90	99	1.75	44.45	0.88	1.95

\*Fitting Lengths listed are for Corroflon braided only hose grades (SS, PB, HB, KYB). Approximately 33% longer lengths apply to the rubber covered hose grades (RC, SI).


..... ......



Nominal	Hose Size	*Fitting I	ength A	Inside Di	iameter I	Weight o	of Fitting
in	mm	in	mm	in	mm	Kg	Lbs
1/2	15	25/8	67	0.38	9.53	0.10	0.22
3/4	20	31/2	89	0.63	15.88	0.18	0.40
1	25	37/8	98	0.80	20.24	0.29	0.64
1 <sup>1</sup> /4	32	4 <sup>3</sup> /8	110	1.03	26.21	0.45	0.99
1 <sup>1</sup> /2	40	5 <sup>1</sup> /8	130	1.25	31.75	0.60	1.32
2	50	5 <sup>1</sup> / <sub>2</sub>	140	1.75	44.45	0.84	1.85
2 <sup>1</sup> / <sub>2</sub>	65	63/4	170	2.25	57.15	1.70	3.75
3	80	6 <sup>3</sup> /4	170	2.63	66.70	2.53	5.58
4	100	7 <sup>1</sup> / <sub>2</sub>	190	3.50	88.90	3.99	8.80

#### **Fixed Female NPT**







Nominal	Hose Size	NPT or BSPT Thread Size	*Fitting Length A		Inside Diameter I		Weight of Fitting	
in	mm	in	in	mm	in	mm	Kg	Lbs
1/2	13	1/2	2.72	69	0.38	9.53	0.18	0.40
3/4	20	3/4	3.54	90	0.63	15.88	0.22	0.49
1	25	1	3.82	97	0.80	20.24	0.33	0.73
1 <sup>1</sup> /2	40	11/2	4.96	126	1.25	31.75	0.75	1.65
2	50	2	5.16	131	1.75	44.45	1.06	2.34

\*Fitting Lengths listed are for Corroflon braided only hose grades (SS, PB, HB, KYB). Approximately 33% longer lengths apply to the rubber covered hose grades (RC, SI).

#### **End Fitting Materials**

- Spigots in Grade 316L SS
- Nuts in Grade 316L SS
- Ferrules, most in Grade 304 SS, some sizes in Grade 316L SS
- Alternatives -
- Cone Seat Female Unions can be supplied in Zinc Plated Carbon Steel if required
- Lug Nuts can be supplied in Gun Metal (Bronze) if required





## **CORROFLON 37° JIC FEMALE FITTINGS** & NPT MALE OR FEMALE UNIONS

#### **End Fitting Specifications**

- SAE J514 37° Flare JIC Female Fitting
- 37° JIC Male-to-NPT Male/Female Adaptors
- NPT Threads to ANSI B2.1

#### **Temperature and Pressure Ratings**


• Same Maximum Working Pressure and Temperature as for the relevant size of Corroflon Hose, on page 5

#### **End Fitting Materials**

- Spigots in Grade 316L SS
- Nuts in 316L SS
- + Ferrules, most in Grade 304 SS, some sizes in Grade 316L SS

**Note** - Not usable with SAE 45° Flare fittings which have the same thread. **Alternatives** - Can be supplied in other materials, such as zinc plated carbon steel, Hastelloy, Monel etc






Nominal Hose Size		37° JIC Thread Size	*Fitting	*Fitting Length A		Hex Size H		Fitting Inner Diameter I		Weight of Fitting	
in	mm	in	in	mm	in	mm	in	mm	Kg	Lbs	
<sup>1</sup> / <sub>2</sub>	13	<sup>3</sup> /4-16	2.13	54	0.88	22.2	0.38	9.5	0.11	0.24	
3/4	20	1 <sup>1</sup> /16-12	2.99	76	1.25	31.7	0.63	15.9	0.15	0.34	
1	25	15/6-12	3.66	93	1.50	38.1	0.80	20.2	0.23	0.52	
1 <sup>1</sup> /2	40	17/8-12	4.17	106	2.25	57.1	1.25	31.7	0.72	1.58	
2	50	21/2-12	4.49	114	2.88	73.0	1.75	44.4	0.99	2.18	


\*Fitting Lengths listed are for Corroflon braided only hose grades (SS, PB, HB, KYB). Approximately 33% longer lengths apply to the rubber covered hose grades (RC, SI).

#### JIC to NPT Male Union (Including a JIC Male-to-NPT Male Adaptor)



Nominal Hose Size		Male Union Length A1		-	ı Inner eter I	Weight of Fitting		
in	mm	in	mm	in	mm	Kg	Lbs	
1/2	13	4.13	105	0.53	13.4	0.17	0.37	
<sup>3</sup> /4	20	4.92	125	0.72	18.3	0.28	0.62	
1	25	5.31	135	0.94	23.8	0.44	0.97	

#### JIC to NPT Female Union (Including a JIC Male-to-NPT Female Adaptor)



Nominal Hose Size		Female Union Length A2		-	j Inner eter I	Weight of Fitting		
in	mm	in	mm	in	mm	Kg	Lbs	
1/2	13	3.62	92	0.39	9.9	0.19	0.42	
3/4	20	4.80	122	0.61	15.5	0.29	0.64	
1	25	5.35	136	0.84	21.4	0.57	1.25	

\*Fitting Lengths listed are for Corroflon braided only hose grades (SS, PB, HB, KYB). Approximately 33% longer lengths apply to the rubber covered hose grades (RC, SI).

#### **CORROFLON PTFE DIP PIPES** STRAIGHT OR 90° ELBOW

#### Fixed Dip Pipes

#### Description

Fixed Dip Pipes are fairly rigid, thick wall PTFE tubes, either straight or 90° elbowed, which are directly crimped to the end of Corroflon hoses. They are designed for insertion into drums, tanks and reaction vessels in order to suction drain (or inject) process fluids transferred through the hose.

#### Materials

- · Standard dip pipes are in anti-static (AS) PTFE
- Ferrules, most in Grade 304 SS, some sizes in Grade 316L SS

#### How to Order

Specify the size and material of the dip pipe, whether it is straight or  $90^{\circ}$  elbowed. Give the length of the straight leg of the dip pipe and the length of the rest of the hose assembly separately.

#### **Maximum Working Pressures**

Dip Pipes are normally only tested to 6 Bar Pressure, and are not suitable for use at pressures higher than 3 Bar. They are usable at negative pressure up to -0.9bar vacuum.

If higher pressure ratings are required, consult Aflex Hose.

#### Lengths

Dip Pipes are supplied as standard in 1 metre straight lengths, but can be supplied in any length to individual requirements.

Nominal Hose Bore Size		Approximate Dip Pipe Dimensions			
		Outside D	iameter D	Inside Diameter I	
in	mm	in	mm	in	mm
3/4	20	0.87	22	0.51	13
1	25	1.14	29	0.83	21
1 <sup>1</sup> /2	40	1.54	39	1.00	27
2	50	2.17	55	1.58	40

#### **Detachable Dip Pipes**

#### Description

As Fixed Dip Pipes above, but connected to the hose through an end fitting, not by crimping direct to the hose.

#### Design

A straight, or 90° elbowed anti-static PTFE Dip Pipe, fitted with a Flange or Cam & Groove Male PTFE Lined & Flared end fitting.

The most usual end fitting is a Cam Male (as shown), so the dip pipe can then be connected to a hose with a Cam Female end fitting.


#### Specifications

As above for Fixed Dip Pipes.


#### Fixed Dip Pipe 90° Elbow



#### Fixed Dip Pipe (Straight)



#### **Detachable Dip Pipe**




## CORROFLON 90° ELBOW FITTINGS PTFE LINED & NON-LINED

#### PTFE Lined 90° Elbow Fittings

All of the PTFE lined end fittings described on previous pages can be fitted as 90° elbow PTFE lined fittings to the design shown, to the sizes listed.


All grades of hose can be used, except PB and KYB.



Hose Bore Size	Off-Set	Fitting Length	Weight of Fitting	
	mm	mm	Kg	Lbs
1″	85	143	0.48	1.07
1 <sup>1</sup> /2″	200	237	1.37	3.03
2"	200	314	1.68	3.70

#### Non-Lined 90° Elbow Fittings

A 90° elbow attached to the hose can be supplied non-PTFE lined, as shown, for any size or grade of hose or type of fittings, to special order.



## **CORROFLON INSULATED HOSE ASSEMBLIES**

#### Purpose

For use in Industrial, Chemical, Pharmaceutical and Biopharma applications where cold media passing through the hose can result in condensation forming on the outside of the hose, which may be undesirable within the application. The insulated hose can also be used with hot media to limit heat losses and to limit the external temperature of the hose for protection of operators. Unlike other designs the insulation and cover is integral to the hose design and will stay in place throughout the hose life.

#### Description

The base hose comprises of a braided hose assembly. The insulated element comprises of a standard 12mm closed-cell fire resistant silicone foam rubber spirally wrapped around the hose, completed with a handwrapped black EPDM rubber cover or a wipe clean Platinum Cured Silicone Cover.

#### Design

Each hose is custom designed and built to suit the requirements of the particular application. Other applications can be considered please consult our technical department.

#### Specification

As for Corroflon GP, SS on pages 6 & 7, except that the minimum bend radius is increased by approx. 25%, there is an increase on the O/D of approx. 25mm and there will be a slight increase in the complete weight of the assembly. The media temperature range as per Corroflon with a stainless steel braid.

#### Limitations

Minimum Aflex Insulated hose assembly length 750mm.

Maximum Aflex Insulated hose assembly length 20mtrs (Where maximum length for the hose size permits).

Not suitable for application where exacting temperature control is required. See CH and ETH section for these applications.





#### **CORROFLON STEAM HEATED HOSE ASSEMBLIES** (CH GRADE)

#### Purpose

For use in applications where the temperature of the process fluid entering the hose assembly must be maintained as it passes through the hose. This is usually required to prevent solidification or an increase in the fluid viscosity. Steam or hot oil heating is preferred to electrical heating in some applications for reasons of availability or safety, but is less controllable.

#### Description

The heating element comprises a small diameter PTFE heating hose, 6mm or 9.5mm bore size, with a single SS wire braid. This is spirally wrapped around the hose, with inlet and outlet ports attached either both at one end or at opposite ends of the hose assembly. In the case of hose assemblies longer than 3 metres, it is usual to have not one but several heating hoses with inlet ports at opposite ends and along the hose. This reduces the effects of temperature loss over the length of the hose assembly. The thermal insulation is closed-cell, fire resistant silicone foam rubber. The outer cover may be SS wire braid with or without a rubber cover if necessary.

#### **CH Hose Assembly**

#### Design

Each hose is custom designed and built to suit the requirements of the particular application. The following information is therefore required:

- Fluid in Hose Assembly
- · Maintained Temperature of Fluid in Hose
- Temperature of Steam or Fluid in the Heating Hose
- Min/Max Ambient Temperature
- External Conditions of Abrasion etc.

#### Specifications

As for Corroflon GP, SS on page 7, except the size range is 1" to 3", the minimum bend radius is tripled, and the outside diameter and weight are significantly increased in line with the particular design. The maximum length of a CH/ETH hose is 10m (33ft).

#### Limitations


1" PTFE lined PN10 flange spigots on heated hoses can only have a maximum flare diameter of 50mm, not 63mm.

If the hose is "hanging", straight or at 90°, under its own weight, special construction is required, so advise Aflex Hose accordingly.

Minimum CH Hose Assembly Length 750mm.

Not recommended for use with PB braid.

#### Small diameter PTFE heating hose, coiled along hose



## **CORROFLON ELECTRICALLY TRACE HEATED HOSE ASSEMBLIES** (ETH GRADE)


#### Purpose

For use in applications where the temperature of the process fluid entering the hose assembly must be regulated as it passes through the hose. This is usually required to prevent solidification or an increase in the fluid viscosity. In some applications, an additional 'heating up' or 'melting' facility is also required. Electrical heating is often preferred to steam heating because it is more convenient, more controllable and usually more readily available. 'Zone 1 Hazardous Area' requirements can be met.

#### Description

The heating element comprises either a resistance element or a self-regulating element spirally wrapped around the hose assembly. Self regulating elements may require a sensor and controller if a specific maintain temperature is required. Please consult Aflex Hose for clarification. Resistance element heated hoses usually also require a temperature sensor to be built in to the construction and must be used in conjunction with a temperature controller. The power leads and (if applicable) temperature sensor leads emerge from the hose assembly at one end, through glands and conduits. The thermal insulation is foam rubber, closed-cell fire resistant silicone foam rubber for temperatures above 80°C. The outer cover may be a Polypropylene Braid or SS wire braid with a rubber cover if necessary.

#### ETH Hose Assembly



#### Design

Each hose is custom designed and built to suit the requirements of the particular application. Application details must be supplied by filling in an "ETH Hose Questionnaire", available from Aflex Hose. Generally, for Hazardous Areas, the Self Regulating type of heating element is employed, with or without a temperature sensor and control, and flameproof glands and conduit are also required. The watts per metre of the heating element, the pitch of the spiral on the hose, and the thickness of the thermal insulation are all calculated in accordance with established formulae to give the required maintained temperature for the process fluid passing through.

#### Specifications

As for Corroflon GP, SS on page 7, except that the minimum bend radius is tripled and the outside diameter and weight are significantly increased in line with the particular design. The maximum length of a CH/ETH hose is 10m (33ft).

#### Limitations

1" PTFE lined PN10 flange spigots on heated hoses can only have a maximum flare diameter of 50mm, not 63mm.

If the hose is "hanging", straight or at 90°, under its own weight, special construction is required, so advise Aflex Hose accordingly.

Minimum ETH Hose Assembly Length, when collars are used 750mm.

#### **CORROFLON STANDARD LABELLING, STREAMLINE TAGGING** & COLOUR CODING SYSTEMS

#### Standard Labelling



All Corroflon hose assemblies are labelled with the following information:

Manufacturer's Name (Aflex Hose Ltd)

Hose Size and Grade

EN16643 and year of standard publication

EN16643 electrical property grade

Max. Working Pressure and test pressure

Working temperature range\*

Unique Serial Number

Month & Year of Manufacture

Aflex Hose Telephone Number

CE Mark (if applicable)

\*Note any restrictions on working pressure resulting from elevated temperatures.

This information is normally laser-etched on to the ferrule.

In some cases, at the discretion of Aflex Hose, the information may be etched on to a thin stainless steel plate which is clamped to the hose, or a loose stainless steel ring mounted on the hose. This may be necessary for example, if the customer requires additional information which may not fit on to the ferrule.

Customers may specify which labelling system they require, and may request additional information on the label.

#### Streamline Tagging



This system is only applicable to the Silicone (SI) rubber covered grades of Corroflon that have a stainless steel (SS) braid.

A label and/or Colour Code is placed around the silicone cover of the hose and then encapsulated by a transparent silicone that is formed into a thin streamlined cover.

Note: 1/2" size, Colour Code only, no text.

#### **Colour Coding**



This system is applicable to all grades of Corroflon hose.

A coloured PTFE spiral strip is wound on to the hose.

It can be left loose, or it can be encapsulated under a transparent, heat-shrunk polyolefin sleeve.

## **HOSE CONFIGURATION & LENGTH CALCULATIONS** - FOR BEND RADIUS

#### **Hose Configuration Requirements**

Hose Assemblies are usually connected at both ends in service. They may then either remain in a fixed, or static configuration or in a flexing, or dynamic configuration.


Minimum Bend Radius (MBR) for the hose as listed in the relevant hose brochure.

contents creates a stress at an angle to the end fitting.


end fittings.

#### (Dynamic) Configuration

#### **INCORRECT** - Hose too short




#### **CORRECT** - No flex at End Fittings




- Whether static or dynamic, the First Rule concerning the configuration of the hose is that the bend radius of the hose must never be less than the
- The most common situation when this is likely to occur is when the hose is flexed at the end fitting, with stress being applied to the hose at an angle to the axis of the end fitting. Typically, this happens either because the length of the hose is too short, or because the weight of the hose plus
- The Second Rule, therefore, if possible, is to design the configuration to ensure that any flexing in the hose takes place away from the

#### (Static) Configuration

**INCORRECT** - Weight of hose is at 90° to Axis of End Fittings



**CORRECT** - No flex at end fittings



**End Fittings** 


#### HOSE CONFIGURATION & LENGTH CALCULATIONS - FOR ABRASION & TORQUE


The Third Rule is that the hose configuration should always be designed, and supported where necessary, to avoid any possibility of external abrasion.


In some cases, the length, configuration and angle of the hose can be designed to avoid abrasion. In others, static or moving support frames or support wheels are required.


**INCORRECT** - Abrasion against hose

**INCORRECT** - Abrasion inside support










**CORRECT** - No abrasion over support


The Fourth Rule is that the hose must not be subjected to torque, either during connection, or as a result of the flexing cycle.


Torque (twist) in the hose can be applied during connection if the hose is accidentally twisted, or if the second end being connected is a screwed connection, and the hose is subjected to torque during final tightening.

In a flexing application, if any flexing cycle of the hose occurs in 3 dimensions instead of 2, then torque will also occur:




**CORRECT** - Flexing movement takes place in 2 dimensions





**INCORRECT** - Flexing movement takes place in 3 dimensions so torque is applied



## HOSE CONFIGURATION & LENGTH CALCULATIONS - FOR LENGTH CALCULATION

#### Calculating the Hose Length

The formula for calculating the bent section of the hose length around a radius is derived from the basic formula that the circumference of a circle =  $2\pi R$ , where R = the radius of the circle, and  $\pi$  = a constant, = 3.142.

So, if the hose goes around a 90° bend, which is 1/4 of a full circumference, and the radius of the bend is R, then the length of the hose around the bend is =  $1/4 \times 2\pi R$ . Or half way round, in a U-shape, =  $1/2 \times 2\pi R$ .

#### Note :

In calculating the length of a hose assembly, the (non-flexible) length of the end fittings must be added in, also the length of any straight sections of hose, as in the following example:

#### Example :

To calculate the length for a 2" bore size hose with flange end fittings, to be fitted in a 90° configuration with one leg 400mm long, the other 600mm long.

Length of Bent Section (yellow) =  $1/4 \times 2\pi R$  (334)

 $= \frac{1}{4} \times 2 \times 3.142 \times 334 =$  **525mm** 

Length of top, Straight Section, including the top end fitting length


	= 600 - 334 =	266mm
Length of bottom end fitting	=	66mm
Total length of Hose Assembly	= 525 + 266 + 66 =	857mm

#### Things to consider

- (a) A hose will normally take the longest radius available to it to go around a corner, not the MBR! Also always remember to include the **non-flexible** end fitting lengths.
- (b) In dynamic applications, remember to always calculate the lengths for the most extended configuration during the flexing cycle, not the least extended.
- (c) If the configuration is simply too complex for calculation, then obtain a length of flexible tubing of some kind, mark on paper, or a wall, or floor, or both where the connection points will be relative to each other, scaled down if necessary, then manually run the flexible tubing between them with full radii round bends. Measure the extended length, then scale up if necessary to determine the approximate length of the hose.

If in doubt, consult Aflex Hose.

36



Note: The bend radius is measured to the inside edge of the hose, For the minimum bend radius refer to page 6.

#### CONDITIONS OF SALE

## CONDITIONS OF SALE CONTINUED

#### 1. Definitions

"Business Days" means a day (other than a Saturday, Sunday or public holiday) when (a) All Contracts shall be deemed to incorporate these Conditions. banks in London are open for business.

"Buyer" means a customer of the Seller

"Conditions" means these terms and conditions for the sale of goods or the supply of services or both

"Contract" means a binding contract for the sale of goods or the supply of services or both made by the Seller and the Buyer.

"Emergency Call-out" means the call-out service for emergency breakdowns of the Buyer's plant or equipment provided by the Seller to the Buyer in accordance with these Conditions in connection with a Contract for the performance of the Services.

manufactured by Seller, and are purchased by Seller from another supplier or manufacturer.

including but not limited to strikes, lock-outs or other industrial disputes (whether Buyer involving the workforce of the Seller or any other party), failure of a utility service or transport network, act of God, epidemic or pandemic, war, riot, terrorism, civil commotion, malicious damage, compliance with any law or governmental order, rule, regulation or direction, accident, breakdown of plant or machinery, fire, flood, storm, default of suppliers or subcontractors.

"Goods" means the goods agreed to be sold by the Seller to the Buyer as detailed in the Order Acknowledgment.

"Intellectual Property Rights" means all copyright, database rights, semi-conductor topography rights, design rights, trademarks, trade names, patents, domain names and any other intellectual property rights of a similar nature (whether or not registered) subsisting anywhere in the world.

#### "Losses" means:

(a) any indirect, special or consequential loss or damage; or

(b) loss of data or other equipment or property; or

(c) economic loss or damage; or

(d) incurring of liability for loss or damage of any nature whatsoever suffered by third parties (including in each case incidental and punitive damages); or

business or damage to goodwill

"Seller" means Aflex Hose Limited.

"Services" means the services agreed to be supplied by the Seller to the Buyer as detailed in the Order Acknowledgment.

"Specification for Goods" means the specification for the Goods that is agreed in writing by the Seller and the Buyer.

"Specification for Services" means the specification for the Services that is agreed in writing by the Seller and the Buyer.

#### 2. Interpretation of Contracts

Contracts for the International Sale of Goods and the international rules for the interpretation of trade terms prepared by the International Chamber of Commerce (INCOTERMS) shall be excluded. The construction, validity and performance of all SALE OF GOODS Contracts shall be governed by English law and, without prejudice to the right of the **5.** The Goods Seller to take action against the Buyer in any other court of competent jurisdiction, any claim or dispute arising from the Contracts shall be subject to the exclusive (a) The Goods are described in the Specification for Goods. The Goods shall comply jurisdiction of and be determined by the courts of England. The taking of proceedings with the Specification for Goods in material respects. Any stated dimension or weight in any one or more jurisdiction shall not preclude the Seller from taking proceedings set out in the Specification for Goods is an estimate only. in any other jurisdiction, whether concurrently or not, to the extent permitted by the law of such other jurisdiction.

a Contract shall in no way affect the validity or enforceability of the remaining and they shall not form part of the Contract. No Contract shall be a contract by provisions in a Contract. Any such provision shall be deemed to be modified to sample the minimum extent necessary to make it valid or enforceable. If such modification (c) The Seller may alter the Specification for Goods: is not possible, the relevant provision shall be deemed severed subject to such consequential modification as may be necessary for the purpose of such severance.

(c) The headings used herein are for convenience only and shall not affect construction

(d) Words in the singular include the plural and in the plural include the singular.

(e) Reference to a Condition is to a Condition of these Conditions unless the context the Seller that is due to: requires otherwise

#### 3. Formation of Contracts and Application of Terms and Conditions

(b) Any variation to these Conditions shall have no effect unless expressly agreed in writing and signed by an authorised signatory of the Seller and any variation of a Contract shall have no effect unless it is in writing and signed by the Seller and the Buyer (or their authorised representatives).

(c) A prospective Buyer shall place its order for goods or services (or both) by completing the Seller's purchase order standard form, if applicable, or by submitting its own purchase order form (in either case, such form is the "Purchase Order"). Each Purchase Order shall be deemed to be an offer by the prospective Buyer to buy the goods or services (or both) of the Seller that are identified in the Purchase Order subject to these Conditions.

"Factored Products" shall mean products which are supplied by Seller, but are not (d) The Purchase Order shall only be deemed to be accepted when the Seller issues to the prospective Buyer an order acknowledgement form which indicates acceptance of the prospective Buyer's offer on these Conditions (the "Order Acknowledgment"). A Contract between the Seller and the Buyer shall come into existence at the time and "Force Majeure Event" means an event beyond the reasonable control of the Seller on the date when the Seller delivers the relevant goods or services (or both) to the

> (e) The Contract shall constitute the entire agreement between the Seller and the Buyer and the Buyer acknowledges that it has not relied on any statement, promise or representation made or given by or on behalf of the Seller that is not set out in the Contract

> (f) The Buyer shall ensure that the description of the goods or services (or both) ordered which is contained in its Purchase Order and any applicable specifications is complete and accurate.

> (g) These Conditions apply to the Contract to the exclusion of all other terms and conditions that the Buyer shall seek to impose or incorporate, or which are implied by trade, custom, practice or course of dealing. These Conditions may be extended by additional terms and conditions issued by the Seller in writing and confirmed in the Order Acknowledament

#### 4. Quotations and Purchase Orders

(a) Any quotation issued by the Seller shall not constitute an offer and is given on the basis that no Contract shall come into existence unless and until the Seller despatches an Order Acknowledgement to the Buyer.

(b) Any quotation issued by the Seller is valid for a period of 5 Business Days for delivery dates and 30 Business Days for prices only after the date of its issue, provided that the Seller has not previously withdrawn it by notice in writing to the Buyer.

(e) any loss of actual or anticipated profit, interest, revenue, anticipated savings or (c) Subject to Condition 4(d), any Purchase Order accepted by the Seller shall be accepted on the basis that the price for the goods or services (or both) shall be that set out in the Seller's quotation on condition that the Seller's quotation is within its period of validity and notice of withdrawal in writing has not been issued by the Seller at the time of acceptance.

> (d) The Seller reserves the right to give in writing notice of the withdrawal of a quotation at any time within the period of validity of the quotation and before the Contract is formed. In the event that the Seller changes the price of any of the goods or services (or both) offered for sale or supply, any existing quotation in respect of those goods or services (or both) shall be deemed to be automatically withdrawn and the Seller shall issue a new quotation to the prospective Buyer.

(e) The prices stated in the Seller's quotations are exclusive of VAT.

(f) All Purchase Orders placed by a prospective Buyer shall be placed by fax, post or (a) The Uniform Law on International Sales, the United Nations Convention on e-mail, or, where agreed in advance in writing by the Seller, by telephone or Seller's

electronic system for prospective Buyers to place orders and make payments.

(b) All performance figures, descriptions (other than any description set out in the Specification for Goods), drawings and samples of Goods are approximate only being (b) The complete or partial invalidity or unenforceability of any provision in intended to serve merely as a guide. The Seller shall not be liable for their accuracy

(i) for the purpose of making changes to the Goods which it can establish to the reasonable satisfaction of the Buyer constitute improvements to the Goods or;

(ii) if required by any applicable statutory or regulatory requirements.

(d) The Seller may increase the price of the Goods by giving notice in writing to the Buyer at any time before delivery, to reflect any increase in the cost of the Goods to (i) any factor beyond the control of the Seller (including foreign exchange) fluctuations, increases in taxes and duties, and increases in the cost of acquirir manufacturing the Goods;

(ii) any request by a Buyer to change the delivery date(s), quantities or type Goods ordered, or the Specification for Goods; or

(iii) any delay caused by any instructions of the Buyer in respect of the Good failure by the Buyer to the give the Seller adequate or accurate informatic instructions in respect of the Goods.

(e) All drawings, designs, and quotations for which goods are not subseque ordered by the Buyer shall remain the property of the Seller and be treate confidential by the Buyer and not used in any way. The Seller shall have no liabili relation to any such drawings, designs or quotation.

(h) The Buyer accepts that Seller is not an expert in the technical features w apply to Factored Products and/or their use in application. Seller's obligation will be to pass on to the Buyer all the written information which Selle itself received regarding the Factored Product, but the Buyer shall be responsib ensuring that this and any other necessary Factored Product information is obta and is reviewed and will decide solely if such data is sufficient to ensure the Factored Product is fit for purpose in the intended usage application. I application requirements apply which are not fully covered by the information w the Buyer can obtain, then the Buyer undertakes not to use or supply the Fact Product for use in that application. The Buyer is also responsible for ensuring the Factored Product will not be subjected to levels of usual or accidental phy abuse in service which would cause the Factored Product to fail. The Buyer ad and acknowledges that Seller, its officers, directors, employees, affiliates representatives shall not be held liable for any claims or obligations arising out o Buyer's failure to fulfil any or all of its responsibilities set forth in this clause 8(h) hereby agrees to indemnify and hold Seller its officers, directors, employees, affi and representatives fully harmless from any and all claims that may arise in rega Factored Products. If the Buyer has any doubts concerning these or any other u conditions and limitation or safety parameters, the Buyer shall consult Seller request a written response to any gueries

#### 5A. UNTESTED HOSE SUPPLIES FOR SELF-ASSEMBLY BY BUYERS ("SAC")

(a) Unless otherwise specified in writing by Seller, "loose" hose supplied (wit end fittings attached) for self-assembly by Buyer (who will cut the hose to length attach end fittings to make up Hose Assemblies for their own use, or for sale to own customers) will not be pressure tested by Seller before supply. Such hydros testing of the hose and the end fitting attachment will be the sole responsi of the Buyer and Buyer warrants and represents that it shall carry out hydrostatic pressure testing on all of its SAC hoses purchased from Seller, adh to the maximum working pressure (MWP) and safety factor of the hose assemb specified in the relevant Seller product brochure (as may be amended from tin time).

(b) When pressure testing braided hoses with a plastic or rubber outer cover cover will mask any signs of leakage for a time. The Buyer agrees and acknowle that in respect of all SAC hoses, after the hydrostatic pressure test, it is fur required to test each covered hose assembly with an internal helium gas pressu 30 Bar (450 psi) for hose sizes up to 1" and 15 Bar (225 psi) for hose sizes above with the hose assembly immersed in water to enable leak detection by gas bub for a minimum test period of 5 minutes.

(c) The Buyer agrees and acknowledges that in respect of all SAC hoses, E alone shall determine and approve the design suitability of the hose assembly f intended use before supply by Seller and that it shall indemnify and hold Seller harmless from any and all claims and losses, whether direct or indirect arising design suitability for a SAC hose.

#### **5B. UNTESTED HOSE ASSEMBLIES**

acknowledges that Seller shall have no liability whatsoever if the Buyer does not Purchase Order being complete and delivery satisfied. comply with the warning that requires pressure testing before use, and agrees to fully 7. Title indemnify and hold Seller fully harmless from any and all claims arising from any use by Buyer or onward sale by Buyer of such untested hose assemblies.

#### 6. Despatch and Delivery

(a) For the purposes of this Condition 6, the "Goods" shall mean the Goods in their (i) the Goods; and entirety where delivery is not by instalments or, where delivery is by instalments, each instalment of the Goods

(b) Unless otherwise agreed in writing by the Seller, delivery of the Goods shall take place at the location stated by the Seller in the Order Acknowledgement (the "Point of Delivery")

(c) Any stated delivery date is an estimate and time for delivery shall not be of the essence. The Seller will use reasonable endeavours to meet any stated delivery date.

2000	If no data for delivery is specified, delivery shall be within a reasonable time
ange ng or	If no date for delivery is specified, delivery shall be within a reasonable time. (d) THE SELLER SHALL NOT BE LIABLE FOR ANY LOSSES (AS DEFINED),
es of	CAUSED DIRECTLY OR INDIRECTLY BY ANY DELAY IN THE DELIVERY OF THE GOODS EVEN IF CAUSED BY THE SELLER'S NEGLIGENCE.
	(e) ANY DELAY IN THE DELIVERY OF THE GOODS SHALL NOT ENTITLE THE
ds or on or	BUYER TO TERMINATE OR RESCIND THE CONTRACT UNLESS SUCH DELAY EXCEEDS ONE HUNDRED AND EIGHTY (180) DAYS.
ently ed as	(f) Delivery of the Goods shall be completed on the arrival of the Goods at the Point of Delivery. Risk in the Goods shall pass to the Buyer on completion of delivery of the Goods.
ity in vhich only r has le for ained	(g) Except insofar as the Contract expressly provides otherwise, standard carriage and packaging is excluded in the price. Seller may select the method of delivery, and charge the Buyer for the cost of carriage. Where the Goods are to be delivered at the Buyer's request by any special or express means, the Seller will charge the Buyer the full cost of carriage. When any special packaging is required (whether at the Buyer's request or because the Seller considers special packaging to be necessary), then the Seller will charge the Buyer the full cost of such packaging.
that f any hich	(h) In contracting for carriage and/or insurance of the Goods in transit, if required by the Contract, the Seller shall be deemed to act solely as agent of the Buyer.
ored	(i) The Buyer must:
that /sical	(i) examine the Goods on delivery;
and of the , and	<ul> <li>(ii) notify the Seller and any carrier in writing of any shortage or damage within four</li> <li>(4) Business Days after the date of delivery and in respect of non-delivery within ten</li> <li>(10) Business Days after the Goods would in the ordinary course of events have been received; and</li> </ul>
iates rd to	(iii) in the case of short or damaged delivery give the Seller a reasonable opportunity to inspect the Goods,
sage	otherwise Goods shall be deemed accepted by the Buyer.
and hout	(j) ANY LIABILITY OF THE SELLER FOR NON-DELIVERY OF THE GOODS SHALL BE LIMITED TO EITHER DELIVERING THE GOODS WITHIN A REASONABLE TIME OR ISSUING A CREDIT NOTE AT THE PRO RATA CONTRACT RATE AGAINST ANY INVOICE RAISED FOR SUCH GOODS.
and their static bility	(k) The Seller may deliver the Goods by instalments, each instalment to be deemed to be a separate Contract. Without limiting the other provisions herein, no failure or defect in delivery in respect of any Contract or instalment shall entitle the Buyer to repudiate or cancel any other Contract or instalment.
such ering oly as ne to r, the	(I) If for any reason the Buyer fails to accept delivery of any of the Goods within two (2) Business Days of the Seller giving notice to the Buyer that the Goods are ready, or the Seller is unable to deliver the Goods on time because the Buyer has not provided appropriate instructions, documents, licences or authorizations for the Goods when they are tendered by the Seller for delivery then, except where such failure is caused by a Force Majeure Event:
dges rther ire of re 1",	(i) delivery of the Goods shall be deemed to have been completed at 9.00 am on the second (2nd) Business Day after the day on which the Seller notified the Buyer that the Goods were ready;
bles,	(ii) risk in the Goods shall pass to the Buyer on completion of delivery; and
Buyer or its fully	(iii) the Seller may store the Goods until delivery takes place, whereupon the Buyer shall be liable for all related costs and expenses (including, without limitation, storage and insurance). The Buyer shall be responsible for all Losses incurred by the Seller where the Buyer fails to accept delivery of Goods.
from	(m) If ten (10) Business Days after the Seller giving notice to the Buyer that the Goods

were ready the Buyer has not accepted delivery of the Goods, the Seller may resell or otherwise dispose of part or all of the Goods.

If Seller agrees under a Purchase Order to attach non-standard end fittings to hose (n) Due to the nature of the production of PTFE hose, Seller reserves the right to call assemblies which the Buyer supplies to Seller, Buyer acknowledges and agrees that, a Purchase Order for bulk hose complete in the following situations: (a) if a product is in some instances, it is not possible to connect such non-standard fittings to the Seller a standard Seller product (as listed in Seller's product brochures) a figure of +10% of pressure testing system. In such cases Buyer agrees that Seller shall be entitled, on original order quantity can be supplied. If the product is a non-standard product and giving notice to Buyer, not to test such Goods. Seller shall label the hose assembly outside the Seller's standard product range the figure of +/- 10% of the original order with a warning that it requires pressure testing before use. The Buyer agrees and quantity can be supplied. Goods supplied within these parameters would result in the

(a) The title in the Goods supplied shall not pass to the Buyer until receipt by the Seller in cleared funds of payment in full (including payment of any default interest) for

(ii) any other goods or services that the Seller has supplied to the Buyer and in respect of which payment is due.

#### (b) Until the title in the Goods passes to the Buyer the Buyer shall:

#### (i) be a bailee of the Goods;

#### CONDITIONS OF SALE CONTINUED

(ii) store the Goods separately from all other goods held by the Buyer so that the (dd) failure by the Buyer to follow good trade practice; Goods remain readily identifiable as the Seller's property;

(iii) not remove, deface or obscure any identifying mark or packaging on or relating Seller;

to the Goods (iv) not fix or annex the Goods to or merge the Goods with any part of the Buyer's

premises, plant or equipment without the Seller's prior consent in writing;

(v) maintain the Goods in satisfactory condition;

Goods against all risks with a reputable insurer which has been approved by the Seller for their full price, and ensure that the Seller's interest in the Goods is noted on the (g) The above warranties shall not apply to consumable items with a limited life insurance policy until title in the Goods passes to the Buyer. If the Buyer fails to insure the Goods the Seller may do so instead on behalf of the Buyer, who shall reimburse the Seller on demand. Until title in the Goods passes to the Buyer, the Buyer shall hold 9. Returns in trust for the Seller the policy and proceeds of insurance;

Conditions 21(a)(iv) to 21(a)(x);

(viii) give the Seller such information relating to the Goods as the Seller may require from time to time: and

(ix) not dispose of, charge or encumber the Goods or any interest in the Goods or purport to do so.

but the Buyer may resell the Goods to an independent third party on arm's length terms in the ordinary course of its business.

(c) If before title to the Goods passes to the Buyer the Buyer becomes subject to any of the events listed in Conditions 21(a)(iv) to 21(a)(x), or the Seller reasonably believes thereof and shall ensure that any person other than the Buyer who acquires or has that any such event is about to happen and gives notice to the Buyer accordingly, then, provided that the Goods have not been resold, or irrevocably incorporated into another product, and without limiting any other right or remedy the Seller may have, (b) The Buyer shall be solely responsible for and shall keep the Seller indemnified the Seller may at any time require the Buyer to deliver up the Goods and, if the Buyer against all Losses incurred by the Seller in relation to any use of the Goods other fails to do so promptly, the Seller may enter any premises of the Buyer or of any third than in strict accordance with the Seller's installation, operating, and maintenance party where the Goods are stored in order to recover them.

#### 8. Warranty for Goods

(a) Subject to Condition 8(b), the Seller warrants that on delivery, and for a period of 24 months (12 months for all Hose Assemblies which are "ETH" ("Electrical Trace Heated") Grade or are Factored Products) from the date of delivery the Goods shall:

- (i) conform with the Specification for Goods; and
- (ii) be free from material defects in material or workmanship.

from the date of delivery such Goods shall:

- (i) conform with the Specification for Goods: and
- (ii) be free from material defects in material or workmanship

(c) Subject to the remainder of this Condition 8, the Seller warrants that if (i) the Buyer provides the Seller with written notification within forty-eight (48) hours of Goods (as set out in either Condition 8(a) or 8(b)) and (iii) on the Seller's examination if there are any special requirements for the Good(s), including special cleaning, such Goods prove defective as to material or workmanship or as to compliance with the relevant Specification for Goods the Seller shall:

(i) give notice to the Buyer that such Goods prove defective as to material or workmanship or as to compliance with the relevant Specification for Goods; and

(ii) following giving notice thereof to the Buyer;

(aa) with respect to Goods which have been manufactured by the Seller, make good the defect without charge by (at the Seller's option) repairing the defective Goods, replacing defective components of the defective Goods, or replacing the defective (a) Where goods are supplied for export from England the following additional Goods (in their entirety) as the Seller in its discretion considers appropriate; or

(bb) with respect to Goods which have been supplied, but not manufactured by the Seller, and to the extent that it is entitled to do so, assign or at its discretion use its reasonable endeavours otherwise to make available to the Buyer, at the Buyer's (b) Charges for the cost of export deliveries and documentation shall be as stated in expense and on the basis of an indemnity (secured if appropriate) against all Losses the Contract. that may be incurred by the Seller in relation thereto, the benefit of any obligations (c) Except where specifically agreed in writing to the contrary, delivery to a Buyer and warranties which relate to such defect which the Seller may be owed by the outside of the United Kingdom will be in accordance with the "Ex Works" rule manufacturer and/or supplier of the Goods or any part or component thereof.

(d) The above warranties shall apply except where the defect in the Goods:

(i) has been caused wholly or partly by deterioration of the Goods which is necessarily incidental to the transit of the Goods

(ii) has been caused while the Goods were at the Buyer's risk by:

subcontractors:

#### (bb) the occurrence of an accident:

(cc) failure by the Buyer to follow the Seller's instructions in relation to the storage, use, installation, commissioning or maintenance of the Goods;

(ee) the Buyer altering or repairing such Goods without the consent in writing of the

(ff) fair wear and tear, negligence or by any abnormal conditions.

(e) Except as provided in this Condition 8, the Seller shall have no liability to the Buyer in respect of the Goods' failure to comply with the warranties set out in this Condition 8

(vi) keep the Goods insured between the passing of risk in the Goods and title to the (f) The terms of these Conditions shall apply to any repaired or replacement Goods supplied by the Seller under Condition 8(c).

expectancy.

(a) The Seller shall not refund the Buyer for any amounts paid by the Buyer in the (vii) notify the Seller immediately if it becomes subject to any of the events listed in event that the Buyer returns the Goods (or part thereof) except with the Seller's prior consent in writing. Where such consent is given, the Buyer agrees to pay to the Seller a minimum handling charge of thirty per cent (30%) of the invoiced value.

> (b) To qualify for any refund, the Goods must be appropriately packed to protect them from being damaged in transit and be received by the Seller in a saleable condition within twenty-two (22) Business Days of delivery to the Buyer. The term "Goods" within this Condition 9(b) has the meaning set out within Condition 6(a).

#### 10. Instructions and Health and Safety at Work

(a) The Buyer shall observe strictly the provisions of the Seller's instructions in writing regarding use and application of the Goods together with any revisions access to the Goods is furnished with and observes such instructions

instructions

(c) The Buyer agrees and acknowledges that for any intended application of the Good(s) in which special conditions apply which are not defined, or not defined sufficiently in the Seller's product brochure, the Buyer shall write to Seller requesting written advice relating to any usage limitations resulting from its special uses or conditions. The Buyer shall be fully liable and responsible for ensuring the design suitability and safety of the Goods in their intended applications, giving particular consideration to any special condition relating to, but not restricted to the chemical and electrostatic compatibility of the fluids or gases passing through, the possibility (b) In respect of Goods which are packages or electrically or electronically controlled of diffusion of fluid or gases through the PTFE hose lining, the possibility of external or actuated Goods, the Seller warrants that on delivery, and for a period of 12 months corrosive conditions, the types and likelihood of excessive mechanical abuse, such as abrasion (internal or external), crushing, excessive flexing or vibrations, etc. and any excessive temperature and/or pressure "pulsing" conditions, or any other condition which may cause premature hose failure. The Buyer shall consider and take account of the degree of risk involved in any potential Goods failure, including the provision of adequate protection in the event of any risk to any persons. In applications where any type of Goods failure would lead to financial losses if the Goods are not discovering a suspected defect, (ii) if requested by Seller (after Buyer has provided replaced immediately, the Buyer agrees and acknowledges that it shall be the Buyer's all relevant information requested by Seller in respect of the suspected defective responsibility to order and hold in stock spare Goods accordingly. The Buyer shall Good(s)), the Buyer returns the Goods within the relevant warranty period for such advise Seller in writing at the time of placing the enquiry and on any Purchase Order or drying, or extra testing requirements which are in addition to normal industrial standards. Mere notice of such additional requirements to Seller however, does not relieve the Buyer of its responsibility and liability for ensuring adequate measures are taken or are in place for such applications nor does the mere notification burden nor transfer to Seller any Buyers' liability that the Buyer has for such intended application.

#### 11. Export Sales

Conditions shall apply, and where there is any conflict between the provisions of this Condition 11 and any other Conditions, the provisions of this Condition 11 shall prevail

from the international rules for the interpretation of trade terms prepared by the International Chamber of Commerce (INCOTERMS). In the case of deliveries outside of the United Kingdom the Seller does not accept any liability for damage to the Goods during transit, or marine or war risks unless otherwise specifically agreed by the Seller.

d) The party which is exporting, in the case of exports, or the party which is (aa) wilful default or negligence by the Buyer or its employees, agents, consultants or importing, in the case of imports, will be responsible for obtaining all necessary licences, (or other governmental authorisations required in connection with any export, re-export, or imports, as the case may be, under the Contract. The parties will co-operate with each other in securing any such licenses or authorisations as may be required and each

#### CONDITIONS OF SALE CONTINUED

any failure or diminution in performance of the Buyer's plant or equipment caused by the plant or equipment, or any part thereof: installation, maintenance or operational instructions; or (ii) being used or operated otherwise than in accordance with the Seller's instructions party since the date of installation or commissioning of the plant or equipment or the date of the immediately preceding visit by the Seller's employee or sub-contractor. additional requirements in writing notified by the Seller to the Buyer in respect of the equipment or any part thereof which is caused directly or indirectly by a breach by the Buyer of this warranty. (k) The Seller reserves the right to replace at the Buyer's cost the Buyer's plant or equipment or any part thereof which is unserviceable or inefficient as the Seller considers reasonably necessary in order to fulfil its obligations to provide the Services in accordance with the specification set out in the Order Acknowledgment. (I) Alternatively, the Seller may charge the Buyer for the reconditioning of any part have the item(s) reconditioned, the Seller reserves the right to amend the scope of the Services as in its absolute discretion it considers necessary. (a) The Buyer shall co-operate with the Seller in all matters relating to the Services, require in order to perform the Services. The Buyer shall ensure that such information is accurate in all material respects. (b) The Buyer shall obtain and maintain any necessary licences, permissions, and consents which may be required before the date upon which the Services are due to subcontractors full and free access to the Buyer's site(s) and to the Buyer's plant and equipment which is the subject of the Contract, subject to the Seller and its reasonable requirements as to site safety and security. If, at the time of any prearranged visit the Seller's employees, agents, consultants and subcontractors are unable to gain access to the Buyer's site(s) or plant or equipment in order to supply the Services, the Seller reserves the right to charge for the time spent attending at the Buyer's site(s) and for the cost of carrying out any subsequent visit. (d) If reasonably required by the Seller, the Buyer shall make available to the Seller a and shall keep all materials, equipment, documents and other property of the Seller (the "Seller Service Equipment") in such storage area in safe custody and at the (e) Prior to any visits by the Seller's employees, agents, consultants or subcontractors, the Buyer will

will provide such statements, certificates and assurances regarding transfer, use, (i) The Seller warrants that in providing the Services it will exercise reasonable disposition, end-use, source of supply, nationalities and re-export of the Goods as care and attention and that it will comply with all applicable laws and regulations. may be required in connection with each party's application for any required license. However the Seller excludes liability for all Losses arising directly or indirectly out of or governmental authorisation. (e) Any government fees or charges in connection with obtaining such licenses or authorisations will be the responsibility of the party which is exporting, in the case of (i) being used or operated otherwise than in accordance with any applicable exports, and the party which is importing, in the case of imports, the Goods. (f) The Buyer undertakes not to: (i) offer the Goods for resale in any country where the Buyer knows the export of or recommendations; or the Goods is prohibited by the US Government, the UK Government, the UN, the EU (iii) having been adjusted, changed or altered in any way by the Buyer or any third or any other relevant organisation; or (ii) offer to sell the Goods to any person the Buyer knows or suspects will subsequently resell the Goods into a country where export of the Goods is prohibited (i) The Buyer warrants to the Seller that the Buyer's plant and equipment is by the US Government, the UK Government, the UN, the EU or any other relevant supplied with water at a quality that complies with BS2486 and is compliant with any organisation (g) The Buyer will indemnify the Seller for all liabilities, loss, damages, costs and Buyer's plant and equipment. The Seller excludes all liability for Losses arising directly expenses awarded against or incurred by the Seller arising out of in connection with or indirectly out of any failure or diminution in performance of the Buyer's plant or any breach of the Buyer's obligations contained in Condition 11(g). (h) The Buyer agrees to provide the Seller with any information the Seller reasonably requires concerning the destination and use of the Goods, to allow the Seller to comply in full with any relevant export legislation. SUPPLY OF SERVICES 12. Period of Supply (a) Unless otherwise specified in the Order Acknowledgment, the agreement for the of the Buyer's plant or equipment that, in the reasonable opinion of the Seller, cannot supply of the Services shall be for a period of one (1) year from the date the Seller be suitably or economically repaired on site. The Seller will provide the Buyer with an issues an Order Acknowledgement to the Buyer in accordance with Condition 3 (d) estimate of reconditioning charges for each item and if the Buyer does not agree to (the "Term for Services"). (b) The Seller reserves the right to increase its price for the Services at any time during the Term for Services. The Seller will give the Buyer notice in writing of any 14. Access to Buyer's Site(s) such increase not less than eight (8) weeks before the proposed date of the increase. If such increase is not acceptable to the Buyer, it shall notify the Seller in writing and shall provide the Seller with such information as the Seller may reasonably within two (2) weeks of the Seller's notice and the Seller shall have the right, without limiting its other rights or remedies, to terminate the Contract by giving four (4) weeks' notice in writing to the Buyer. 13. Performance of Services (a) The Seller agrees to provide the Services in accordance with the Specification start. for Services in all material respects, and to supply as necessary spare or replacement (c) The Buyer shall permit the Seller, its employees, agents, consultants and parts and/or consumables, to the Buyer's plant and/or equipment at the sites(s) specified in the Seller's Order Acknowledgment. (b) If the Seller agrees to supply spare or replacement parts and/or consumables, employees, agents, consultants and subcontractors complying with the Buyer's such supply will be strictly on the basis of these Conditions. (c) Any stated performance date is an estimate only and time for performance of the Services shall not be of the essence. The Seller shall use reasonable endeavours to meet any stated performance date. If no date for performance is specified, the Services shall be performed within a reasonable time (d) THE SELLER SHALL NOT BE LIABLE FOR ANY LOSSES (AS DEFINED), CAUSED DIRECTLY OR INDIRECTLY BY ANY DELAY IN THE PERFORMANCE OF THE secure storage area at the Buyer's site(s) for storage of the Seller's service equipment SERVICES EVEN IF CAUSED BY THE SELLER'S NEGLIGENCE. (e) SUBJECT TO CONDITION 13(G), ANY DELAY IN THE PERFORMANCE OF THE Buyer's risk. The Buyer's hall not dispose of the Seller Service Equipment other than SERVICES SHALL NOT ENTITLE THE BUYER TO TERMINATE OR RESCIND THE in accordance with the Seller's instructions in writing. CONTRACT UNLESS SUCH DELAY EXCEEDS ONE HUNDRED AND EIGHTY (180) DAYS (f) SUBJECT TO CONDITION 13(G), THE SELLER'S LIABILITY FOR NON-

PERFORMANCE OF SERVICES SHALL BE LIMITED TO EITHER PERFORMING THE (i) strip back any pipe lagging; SERVICES WITHIN A REASONABLE TIME OR ISSUING A CREDIT NOTE AT THE PRO (ii) supply and erect suitable scaffolding (if required) to allow working access to the RATA CONTRACT RATE AGAINST ANY INVOICE SUBMITTED TO THE BUYER FOR Buyer's plant and equipment; and THE SERVICES. (iii) supply any necessary lifting equipment and required operators.

(g) If the Seller's performance of the Services is prevented or delayed by the Buyer or (f) Following any visits by the Seller's employees, agents, consultants or by the failure of the Buyer to perform any of its obligations under the Contract ("Buyer subcontractors, the Buyer will be responsible for the reinstatement of any pipe Default") then upon the Seller giving the Buyer notice in writing that there has been lagging and the dismantling of any scaffolding erected. a Buver Default:

(i) the Seller shall without limiting its other rights or remedies have the right to to the extent that the Buyer Default prevents or delays the Seller's performance of the Services:

(h) The Buyer will procure that the Seller's employees, agents, consultants and subcontractors are covered by the Buyer's third party liability insurance policy of an (ii) the Seller shall not be liable for any Losses incurred by the Buyer arising directly amount of not less than three million pounds (£3,000,000) per occurrence whilst such or indirectly from the Seller's failure or delay in performing the Services; and employees or subcontractors are on the Buyer's site(s).

(iii) the Buyer shall reimburse the Seller on demand for all Losses incurred by the Seller arising directly or indirectly from the Buyer Default.

(h) The Seller reserves the right, at the Seller's discretion, to employ subcontractors to perform all or any part of the Services (including, without limitation, to commission, install, maintain or repair any parts or equipment) on behalf of the Seller.

(g) The Buyer will provide the Seller's employees, agents, consultants and subcontractors with all specialist safety clothing or equipment as may be necessary suspend performance of the Services until the Buyer remedies the Buyer Default and to meet the Buyer's health and safety and environmental rules (excluding hard hat, to rely on the Buyer Default to relieve it from the performance of any of its obligations safety glasses, overalls and protective shoes which will be provided by the Seller).

#### CONDITIONS OF SALE CONTINUED

(i) Emergency Call-outs are intended for genuine emergency breakdown of the writing. Buyer's plant or equipment which is the subject of the Contract only and will (b) In the event of the Seller agreeing to the Buyer cancelling all or any part of the be charged by the Seller to the Buyer at the appropriate daily rate specified in Contract, the Seller may, without prejudice to any other rights against the Buyer which the Order Acknowledgment. Each Emergency Call-out will be charged as one (1) Acknowledgment for the supply of the Services.

or control (or be deemed to control) any part of the Buyer's site(s) and/or hold or sent be fixed with any duties or liabilities under health and safety laws or regulations or (c) In the event that the Seller agrees to cancellation of a Contract in respect of the common law in relation to any part of the Buyer's site(s).

#### GENERAL

#### 15. Payment and Other Buyer Obligations

(a) In respect of the Goods, subject to Condition 15(d) the Seller shall invoice the Buyer for the full purchase price of the Goods on or at any time after the despatch of the Goods.

(b) In respect of the Services, the Seller shall invoice the Buyer for the Services either (i) the Intellectual Property Rights in the Goods and any materials prepared by the monthly or quarterly as set out in the Contract.

(c) In the event that the Buyer chooses to purchase additional Goods or Services from the Seller that are not set out in the Contract but which are related to the Materials") are the Property of the Seller or the third party manufacturers of the Goods Contract, the terms of such Contract will be deemed to apply to such additional (as applicable); Goods or Services and the Seller will invoice the Buyer for such Goods and Services (ii) nothing in these Conditions or in a Contract shall be construed as conferring any pursuant to Condition 15(a) or 15(b), as appropriate, under the original Purchase licence or granting any rights in favour of the Buyer in the Intellectual Property Rights Order number unless otherwise agreed between the parties

(d) The Seller may in its absolute discretion agree in writing to the Buyer paying for the Goods in instalments, or may agree in writing to extend credit to the Buyer in respect of the payment for Goods. In the event that the Seller agrees to payment by instalments or extends credit in respect of the payment by the Buyer for Goods, (iii) any goodwill in any trade marks affixed or applied to the Goods shall enure to the the Seller shall invoice the Buyer monthly for agreed instalments of the purchase sole benefit of the Seller or any other owner of the trade marks from time to time. price. The Seller may in its absolute discretion by notice in writing to the Buyer (b) The Buyer shall not repackage the Goods and shall not without the Seller's prior withdraw (with immediate effect) the Buyer's right to credit or to pay for the Goods by instalments.

(e) The Buyer shall pay each invoice submitted by the Seller:

(i) within the earlier of thirty (30) days of the date of the invoice or such other period seek to register any trade mark or trade name (including any company name) which is of time after the date of the invoice as has been agreed in the Contract; and

(ii) in Sterling or such other currency as the Seller may from time to time agree in writing) to a bank account nominated in writing by the Seller.

(f) Time is of the essence in relation to payment.

(g) All amounts payable by the Buyer under the Contract are exclusive of VAT chargeable from time to time. Where any taxable supply for VAT purposes is made (i) modify or replace the Goods in order to avoid the infringement; or under the Contract by the Seller to the Buyer, the Buyer shall, on receipt of a valid (ii) procure for the Buyer the right to continue using the Goods; or VAT invoice from the Seller, pay to the Seller such additional amounts in respect of (iii) repurchase the Goods at the price paid by the Buyer, less depreciation at the rate VAT as are chargeable on the supply of the Services or the Goods at the same time as the Seller applies to its own equipment payment is due for the supply of the Services or the Goods

(h) The Buyer shall make all payments due under the Contract in full without any deduction whether by way of set-off, counterclaim, discount, abatement or otherwise (i) any actual, threatened or suspected infringement of any of the Intellectual Property unless required by law.

(i) No payment shall be deemed to have been received until the Seller has received cleared funds.

(j) All payments payable to the Seller under the Contract shall become due immediately on its termination despite any other provision

(k) If the Buyer fails to pay the Seller any sum due pursuant to the Contract by the due date for payment:

(i) the Buyer shall be liable to pay interest to the Seller at the maximum rate allowed not make any admissions or statements in respect of or compromise any such claim by applicable law; and

(ii) the Seller may, in its absolute discretion and without liability to the Buyer, (g) In the event of any claim, proceeding or suit by a third party against the Buyer suspend performance of its obligations under the Contract and under any or all other alleging an infringement of such party's rights by any of the Intellectual Property Contracts between the Seller and the Buyer or terminate the Contract and any or all Rights in the Goods or the Goods Materials (or both), the Seller shall defend the claim, other Contracts between the Seller and the Buyer with immediate effect.

(I) If the Buyer pays any amount to the Seller without apportioning it between (i) the Buyer promptly notifying the Seller in writing of any such claim, proceeding or specific debts or liabilities, the amount paid shall be apportioned as the Seller thinks suit; and fit. The Seller may attribute the entirety of an amount paid to one or more specific (ii) the Seller being given sole control of the defence of the claim, proceeding or items in respect of which payment is due, rather than to all the items in respect of which payment is due.

(m) Buyer shall comply with all applicable laws, statutes, regulations and codes from with modifications to the Goods or the Goods Materials (or both) made by anyone time to time in force, including those related to data protection and to anti-bribery except the Seller or its authorised representative, or out of use or annexation of the and corruption. Buyer must comply with the requirements of the United Kingdom Goods or the Goods Materials (or both) with or to products or third party materials not Bribery Act 2010 (the "Act") and shall not engage in any activity, practice or conduct specified or expressly approved in advance in writing by the Seller, or where the claim, which would constitute an offence under sections 1, 2, or 6 of the Act if such activity, proceeding or suit arises from the Seller's adherence to the Buyer's requested changes practice or conduct had been carried out in the United Kingdom. Additionally, Buyer to the Specification for Goods or from infringing items of the Buyer's origin, design or shall comply, and shall ensure compliance of any party with which it subcontracts selection. complies, with the requirements of the United Kingdom Modern Slavery Act (2015), (h) The Seller shall reimburse the Buyer with an amount equal to any liability assessed including ensuring that all forms of forced labour are eliminated from its business.

#### 16. Cancellation

(a) No contract shall be cancelled by the Buyer except with the Seller's prior consent in

it may have, require the Buyer to pay a cancellation charge. Any cancellation charge additional day of Services over and above the number of days specified in the Order will correspond to the type of contract being cancelled. Contracts for bespoke Goods manufactured by the Seller to the Buyer's specifications may be subject to a cancellation (j) The Buyer acknowledges and agrees that the Seller shall at no time own, occupy charge of 100% of the price of the Contract after the Order Acknowledgement has been

> supply of Goods or Services (or both) which have been ordered to comply with the Buyer's special requirements, the Buyer shall be liable for all costs incurred by the Seller up to the time of cancellation of the Contract in addition to payment of a cancellation charge pursuant to Condition 16(b).

#### 17. Intellectual Property

#### (a) The Buyer acknowledges that:

Seller or on its behalf which relate to the Goods and their development (including, without limitation, drawings, designs, samples, models and similar items) (the "Goods"

in the Goods or the Goods Materials. The Buyer may re-sell the Goods subject to the Seller's right to control the use of its trade marks within the European Economic Area or iurisdiction into which the Goods are sold and the Buyer shall assist the Seller as required in preventing parallel importers from diluting the Seller's rights; and

consent in writing allow any trade marks of the Seller or other words or marks applied to the Goods to be obliterated, obscured or omitted or add any additional marks or words.

(c) The Buyer shall not use (other than pursuant to these Conditions or a Contract) or identical to, confusingly similar to, or incorporates any trade mark or trade name which the Seller owns or claims rights in anywhere in the world.

(d) If at any time it is alleged that the Goods infringe the rights of any third party or if, in the Seller's reasonable opinion, such an allegation is likely to be made, the Seller may at its option and its own cost:

(e) The Buyer shall promptly notify the Seller of:

Rights in the Goods or the Goods Materials (or both) which comes to the Buyer's notice;

(ii) any claim by any third party that comes to the Buyer's notice that the sale or advertisement of the Goods or the use of the Goods Materials (or both) infringes the rights of any person

(f) The Buyer agrees (at the Seller's request and expense) to do all such things as may be reasonably required to assist the Seller in taking or resisting any proceedings in relation to any infringement or claim referred to in Condition 17(e), and the Buyer shall other than with the prior written consent of the Seller

proceeding or suit at the Seller's expense, subject to:

suit, and provided that the Seller shall not be liable and shall not defend the claim. proceeding or suit to the extent that such infringements arise out of or in connection

against the Buyer by final judgment on account of an infringement described in Condition 17 (g).

## CONDITIONS OF SALE CONTINUED

(i) All Intellectual Property Rights in the or arising out of the or in connection with the sued against, the whole or any part of its assets and such attachment or process is not Services shall be owned by the Seller discharged within fourteen (14) days

(i) All Intellectual Property Rights in the materials, equipment, documents and other (viii) an application is made to court, or an order is made, for the appointment of an property of the Seller are the exclusive property of the Seller or of its licensors and shall administrator or if a notice of intention to appoint an administrator is given or if an be returned to the Seller on demand. administrator is appointed over the Buver;

#### 18. Trade Prohibitions

(a) The Buyer undertakes to the Seller that the Buyer shall not re-sell or otherwise to appoint or has appointed an administrative receiver; of the United Stated of America or a member state of the European Union ("Sanctioned receiver is appointed over the assets of the Buyer; Third Party").

grounds to believe that the Buyer intends to re-sell or otherwise supply the Goods to a events mentioned in Conditions 21(a)(iv) to Condition 21(a)(x) (inclusive); Sanctioned Third Party the Seller may upon giving notice thereof to the Buyer refuse to (xii) the Buyer suspends, threatens to suspend, ceases or threatens to cease to carry on, deliver the whole or any part of the Goods and shall have no liability to the Buyer for such all or substantially the whole of its business; refusal

#### 19. Limitation and Exclusion of Liabilities

(a) SUBJECT TO AND WITHOUT LIMITING CONDITION 19(B) OR ANY OTHER been placed in jeopardy. CONDITION, THE SELLER SHALL NOT BE LIABLE TO THE BUYER WHETHER IN CONTRACT, TORT (INCLUDING NEGLIGENCE), BREACH OF STATUTORY DUTY, OR OUT OF OR IN CONNECTION WITH ANY CONTRACT FOR THE SUPPLY OF GOODS AND/OR SERVICES (OR THAT PART OF A CONTRACT WHICH RELATES TO GOODS AND/OR SERVICES).

exclude its liability for fraud or fraudulent misrepresentation or for death or personal has not passed to the Buyer ("Relevant Goods"); subcontractors

CONDITION, THE SELLER'S TOTAL LIABILITY TO THE BUYER IN RESPECT OF ALL Buyer's premises, plant or equipment. OTHER LOSS ARISING OUT OF OR IN CONNECTION WITH ANY CONTRACT FOR (c) All disputes arising out of or in connection with the Contract shall be submitted to TO BUYER'S CLAIM

(d) THE BUYER ACKNOWLEDGES AND AGREES THAT THE LIMITED WARRANTIES 22. Confidentiality AND ALL LIMITATIONS AND EXCLUSIONS OF THE SELLER'S LIABILITY SET OUT IN

Each of the Seller and the Buyer (the "Receiving Party") shall keep in strict confidence all technical or commercial know-how, specifications, inventions, processes or initiatives which are of a confidential nature and have been disclosed to the Receiving Party by the other party ("Disclosing Party"), its employees, agents or subcontractors, and any other such confidential information to those of its employees, agents and subcontractors who need to know it for the purpose of discharging the Receiving Party's obligations under the Contract, and shall ensure

THESE CONDITIONS ARE REASONABLE AND ARE REFLECTED IN THE PRICE OF THE GOODS OR SERVICES (OR BOTH) (AS APPLICABLE) AND THE BUYER SHALL ACCEPT **RISK OR INSURE ACCORDINGLY (OR BOTH).** The Seller shall have no responsibility for any Losses incurred by the Buyer in the confidential information concerning the Disclosing Party's business, its products and event that any information in any quotation or Order Acknowledgement is applied in services which the Receiving Party may obtain. The Receiving Party shall only disclose connection with products other than the Goods and Services. (f) This Condition 19 shall survive the termination or cancellation of the Contract. 20. Force Majeure

(a) The Seller shall not be liable to the Buyer as a result of any delay or failure to perform its obligations under the Contract as a result of a Force Majeure Event.

limiting its other rights or remedies, have the right to terminate the Contract with the 23. Miscellaneous Buyer immediately by giving notice in writing to the Buyer.

#### 21. Events of Default, Termination, Repossession, Suspension; Dispute Resolution

(a) The Seller may terminate the Contract with immediate effect by giving notice in (b) If the Buyer comprises two or more persons, their obligations are joint and several. writing to the Buver if:

(c) The Buyer shall not assign, transfer, mortgage, charge, sub-contract, or otherwise (i) the Buyer fails to pay any amounts due under the Contract on the due date for dispose of or deal in any Contract or any rights or obligations (or both) (as applicable) payment; or thereunder in whole or in part without the Seller's prior consent in writing. Any such (ii) the Buyer otherwise breaches the Contract with the Seller and the breach, if action purported to be taken by the Buyer without the Seller's prior consent in writing remediable and previously notified in writing to the Buyer, is not remedied within five shall be void. (5) Business Days of the Buyer receiving such notice; or

(iii) the Seller terminates any other Contract between the Seller and the Buyer; or

(iv) the Buyer is or otherwise becomes insolvent or unable to pay its debts or suspends any Contract or any part of it to any person, firm or company. admits its inability to pay its debts; or

payment of its debts or threatens to do so or is unable to pay its debts as they fall due or (e) A waiver by the Seller of any right under the Contract or law will only be effective if it is in writing. Any failure or delay by the Seller in exercising, or any partial exercise by the Seller, of any right or remedy under the Contract or by law shall not constitute as a (v) the Buyer commences negotiations with all or any class of its creditors with a view to rescheduling any of its debts, or makes a proposal for or enters into any compromise waiver of that or any other right or remedy. No single exercise by the Seller shall prevent or arrangement with its creditors other than for the sole purpose of a scheme for a the further exercise of that or any other right or remedy. solvent amalgamation: (f) Any waiver by the Seller of any breach of, or any default under, any provision of the

Contract by the Buyer shall not be deemed a waiver of any subsequent breach or default (vi) a petition is filed, a notice is given, a resolution is passed, or an order is made, for or in connection with the winding up of the Buyer other than for the sole purpose of a and shall no way affect the other terms of the Contract. (g) No term of the Contract shall be enforceable by any person that is not a party to it. scheme for a solvent amalgamation:

distress, execution, sequestration or other such process is levied or enforced on or

(ix) the holder of a qualifying charge over the assets of the Buyer has become entitled

supply the Goods to a third party which is the subject of any statutory trade prohibition (x) a person becomes entitled to appoint a receiver over the assets of the Buyer or a

(xi) any event occurs, or proceeding is taken, with respect to the Buyer in any (b) Without prejudice to Condition 18(a), if the Seller shall have notice of or reasonable jurisdiction to which it is subject that has an effect equivalent or similar to any of the

(xiii) the Buyer's financial position deteriorates to such an extent that in the Seller's opinion the Buyer's capability to adequately fulfil its obligations under the Contract has

(b) In the event that the Seller terminates the Contract pursuant to Condition 21(a) the OTHERWISE, FOR ANY LOSSES (AS DEFINED) ARISING DIRECTLY OR INDIRECTLY Conditions or otherwise) by notice in writing to the Buyer do any one or (to the extent Seller may (in its absolute discretion and without prejudice to its other rights under these not inconsistent with one another) more of the following

> suspend any deliveries of Goods to be made under any contract with the Buyer; (i)

(b) Notwithstanding any other terms of these Conditions the Seller does not limit or (ii) revoke any express or implied authority to sell or use any Goods the title in which

injury resulting from its negligence or the negligence of its employees, agents or (iii) require the Buyer to deliver to the Seller any Relevant Goods; and the Buyer shall do so, failing which the Seller may enter the premises where the Relevant Goods are or are (c) SUBJECT TO AND WITHOUT LIMITING CONDITION 19(B) OR ANY OTHER thought to be and repossess the Goods, without liability for any resulting damage to the

THE SUPPLY OF GOODS AND/OR SERVICES (OR THAT PART OF A CONTRACT the International Court of Arbitration of the International Chamber of Commerce and WHICH RELATES TO GOODS AND/OR SERVICES), WHETHER IN CONTRACT, TORT shall be finally settled under the Rules of Arbitration of the International Chamber of (INCLUDING NEGLIGENCE), BREACH OF STATUTORY DUTY, OR OTHERWISE, SHALL Commerce by one or more arbitrators appointed in accordance with the said Rules. The IN NO CIRCUMSTANCES EXCEED THE VALUE OF THE CONTRACT WHICH GAVE RISE place of arbitration shall be London with the laws of England governing the Contract. The language of the arbitration shall be English.

that such employees, agents and subcontractors comply with the obligations set out in this Condition 22 as though they were a party to the Contract. The Receiving Party may also disclose such of the Disclosing Party's confidential information as is required to be (b) If the Force Majeure Event prevents the Seller from providing any of the Services disclosed by law, any governmental or regulatory authority or by a court of competent or Goods (or both) for more than forty-four (44) Business Days, the Seller shall, without jurisdiction. This Condition 22 shall survive termination or cancellation of the Contract.

(a) The Seller's rights under these Conditions are in addition to any other rights which the Seller may have under the general law or otherwise.

(d) The Seller may at any time assign, transfer, mortgage, charge, sub-contract or otherwise dispose of or deal in its rights or obligations (or both) (as applicable) under

(vii) a creditor or encumbrancer of the Buyer attaches or takes possession of, or a (h) This Condition 23 shall survive termination or cancellation of the Contract.

## **CONDITIONS OF SALE CONTINUED**

#### 24. Notices

(a) Any notice to be given by the Buyer under these Conditions or any relevant Contract to the Seller shall be in writing and given by prepaid first class post or hand-delivered to Aflex Hose Limited, Bradley Business Park, Huddersfield, West Yorkshire, HD2 1GZ or to such other address or for the attention of such person as the Seller may notify to the Buver.

(b) Any notice to be given by the Seller under these Conditions or any relevant Contract to the Buyer shall be in writing and given by prepaid first class post or hand-delivered to any address from which the Seller has received communications from the Buyer in connection with these Conditions or the Contract.

(c) Notices shall be deemed to have been received:

(i) if sent by prepaid first class post, two (2) Business Days after posting (exclusive of the day of posting); or

(ii) if delivered by hand, on the day of delivery.

## BIOFLEX ULTRA CORROFLON CORROLINE+ PHARMALINE N&X HYPERLINE FX VISIFLON

#### UK

Dyson Wood Way Bradley Business Park Huddersfield West Yorkshire, HD2 1GZ

Tel: +44 (0) 1422 317200

Bucks County Pa 18947

32 Appletree Lane

USA

Pipersville

Tel: 215 - 766 - 1455 Fax: 215 - 766 - 1688





