

# NR Metering hose 65

NR Metering hose

**Bredel**

Hose Pumps

## Features and benefits

- Manufactured for high consistency and repeatability
- Consistent capacity over the full hose life, independent of varying suction and discharge conditions
- Outstanding abrasion resistance from extruded inner layer
- Precision machined to ensure critical tolerances are maintained
- Pressure capability up to 16 bar (232 psi)
- Suction capability up to 9.5 mWC (374 inWC)
- Max. fluid temperature: 80 °C (176 °F), Min. fluid temperature: -20 °C (-4 °F)



## Technical specifications

	NR Metering hose 65
Max. operating pressure	16 bar
Max. suction capability	9.5 mWC
Max. suction capability	374 inWC
Suction capability (80% Flow rate)	8 mWC
Suction capability (80% Flow rate)	315 inWC
Fluid temperature range	-20 to 80 °C
Fluid temperature range	-4 to 176 °F
Bore size	65 mm
Bore size	2.56 in
Wall thickness	17.1 mm
Wall thickness	0.673 in
Length	2.31 m
Length	91.1 in
Weight	12 kg
Weight	26.46 lbs

Your local Bredel sales office/distributor can advise the right hose for your application. For best pump performance use Bredel Genuine Hose Lubricant

## Materials of construction

	NR Metering hose 65
Material	Natural rubber (NR)
Inner layer	Natural rubber (NR)
Outer layer	Natural rubber (NR)

## Hose composition



Hose composition	
1	Rough hose surface prior to machining
2	Precision machined NR outer layer
3	Four nylon cord reinforcement layers
4	Inner layer available in NR

## Product codes

High precision pump element machined for

**A** — **Bredel 25**

**B** — **28-1000059**

**C** — **25 mm**

**D** — **NR**

**E** — **METERING**

**E** — **16 bar 230 psi**

**F** — **NM3H**

Wilson-Marlow Bredel B.V. Delden, Netherlands

**Bredel**  
Hose Pumps  
Made in the Netherlands

## Product codes

	Label codes
A	Pump type
B	Re-order number
C	Bore size
D	Material of the inner layer
E	Maximum permitted pressure
F	Factory code [material; year; month]

On one end of each hose the factory code [material; year; month] and the batch number are engraved.

Year: last digit (7 = 2017)

Month: A = Jan, E = May

Material: E = F-NBR, M = CSM, NM or NT = NR, P = NBR, S = EPDM

---

Disclaimer: The information contained in this document is believed to be correct at the time of publication, but Watson-Marlow Bredel BV accepts no liability for any error it contains, and reserves the right to alter specifications without prior notice. All mentioned values in this document are values under controlled circumstances at our test bed. Actual flow rates achieved may vary because of changes in temperature, viscosity, inlet and discharge pressures and/or system configuration. APEX, DuCoNite, Bioprene and Bredel are registered trademarks.

[wmfts.com/global](http://wmfts.com/global)



31 August 2023